

SIEMENS

SITRANS F

Electromagnetic flowmeters SITRANS MAG 6000 I/6000 I Ex de

Operating Instructions

7ME693 (MAG 6000 I)

| | |
|--|-----------|
| <u>Introduction</u> | 1 |
| <u>Safety notes</u> | 2 |
| <u>Description</u> | 3 |
| <u>Installing/Mounting</u> | 4 |
| <u>Connecting</u> | 5 |
| <u>Commissioning</u> | 6 |
| <u>Functions</u> | 7 |
| <u>Alarm, error, and system messages</u> | 8 |
| <u>Service and maintenance</u> | 9 |
| <u>Troubleshooting/FAQs</u> | 10 |
| <u>Technical data</u> | 11 |
| <u>Spare parts/Accessories</u> | 12 |
| <u>Menu diagrams</u> | A |
| <u>Factory settings</u> | B |
| <u>Control drawing</u> | C |

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

| |
|--|
| ⚠ DANGER |
| indicates that death or severe personal injury will result if proper precautions are not taken. |

| |
|---|
| ⚠ WARNING |
| indicates that death or severe personal injury may result if proper precautions are not taken. |

| |
|--|
| ⚠ CAUTION |
| indicates that minor personal injury can result if proper precautions are not taken. |

| |
|--|
| NOTICE |
| indicates that property damage can result if proper precautions are not taken. |

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

| |
|--|
| ⚠ WARNING |
| Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed. |

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

| | | |
|----------|---|-----------|
| 1 | Introduction..... | 7 |
| 1.1 | Preface..... | 7 |
| 1.2 | Items supplied..... | 7 |
| 1.3 | Revision history..... | 7 |
| 1.4 | Device identification..... | 8 |
| 1.5 | Further Information..... | 9 |
| 2 | Safety notes..... | 11 |
| 2.1 | General safety instructions..... | 11 |
| 2.2 | Laws and directives..... | 11 |
| 2.3 | Installation in hazardous area..... | 12 |
| 2.3.1 | ATEX 2 GD approval..... | 13 |
| 2.3.2 | FM/CSA Class I, Zone 1 approval..... | 17 |
| 2.3.3 | FM Class I, II, III, Div 1 approval..... | 18 |
| 3 | Description..... | 19 |
| 3.1 | Applications..... | 19 |
| 3.2 | System components..... | 19 |
| 3.3 | Design..... | 20 |
| 3.4 | Features..... | 21 |
| 3.5 | Theory of operation..... | 21 |
| 4 | Installing/Mounting..... | 23 |
| 4.1 | Installation safety precautions..... | 23 |
| 4.2 | Installation conditions..... | 23 |
| 4.3 | Compact installation..... | 24 |
| 4.4 | Remote installation..... | 25 |
| 4.4.1 | Wall mounting using standard mounting plate..... | 27 |
| 4.4.2 | Pipe or wall mounting with assembly bracket..... | 27 |
| 5 | Connecting..... | 29 |
| 5.1 | Safety precautions..... | 30 |
| 5.2 | Electrical connection..... | 31 |
| 5.3 | Connection of sensor and transmitter in remote version..... | 34 |
| 5.4 | Wiring in hazardous area..... | 37 |
| 5.5 | Connection of bus communication add-on modules..... | 38 |
| 5.6 | Reassembling the device..... | 38 |

| | | |
|-----------|---|-----------|
| 6 | Commissioning..... | 41 |
| 6.1 | Local user interface..... | 41 |
| 6.2 | Menu structure..... | 43 |
| 6.3 | Changing password..... | 43 |
| 6.4 | Changing basic settings..... | 44 |
| 6.5 | Changing operator menu setup..... | 47 |
| 6.6 | Changing language..... | 48 |
| 7 | Functions..... | 49 |
| 7.1 | Introduction..... | 49 |
| 7.2 | Output settings..... | 49 |
| 7.3 | External input..... | 50 |
| 7.4 | Sensor characteristics..... | 51 |
| 7.5 | Reset mode..... | 51 |
| 7.6 | Service mode..... | 51 |
| 8 | Alarm, error, and system messages..... | 53 |
| 8.1 | Diagnostics..... | 53 |
| 8.2 | List of error numbers..... | 55 |
| 9 | Service and maintenance..... | 57 |
| 9.1 | Maintenance..... | 57 |
| 9.2 | Certificates..... | 57 |
| 9.3 | Technical support..... | 57 |
| 9.4 | Return procedures..... | 58 |
| 10 | Troubleshooting/FAQs..... | 61 |
| 10.1 | Troubleshooting guide..... | 61 |
| 10.2 | Transmitter check list..... | 62 |
| 11 | Technical data..... | 65 |
| 11.1 | Technical specifications..... | 65 |
| 11.2 | Dimensions and weight..... | 67 |
| 11.3 | Accuracy..... | 68 |
| 11.4 | Output characteristics..... | 69 |
| 11.5 | Cable data..... | 71 |
| 11.6 | Cable requirements..... | 72 |
| 12 | Spare parts/Accessories..... | 73 |
| 12.1 | Ordering of spare parts..... | 73 |
| 12.2 | Accessories..... | 73 |

| | | |
|----------|---|------------|
| 12.3 | Spare parts..... | 74 |
| A | Menu diagrams..... | 75 |
| A.1 | Transmitter menu overview..... | 75 |
| A.2 | Basic settings..... | 77 |
| A.3 | Current output..... | 78 |
| A.4 | Digital output - pulse..... | 79 |
| A.5 | Digital output - frequency..... | 79 |
| A.6 | Error level..... | 79 |
| A.7 | Error number..... | 80 |
| A.8 | Direction/limit..... | 80 |
| A.9 | Batch..... | 81 |
| A.10 | External input..... | 82 |
| A.11 | Sensor characteristics..... | 83 |
| A.12 | Reset mode..... | 84 |
| A.13 | Service mode..... | 85 |
| A.14 | Operator menu setup..... | 86 |
| A.15 | Product identity..... | 87 |
| A.16 | Add-on communication module..... | 88 |
| B | Factory settings..... | 89 |
| B.1 | Transmitter factory settings..... | 89 |
| B.2 | 50 Hz Dimension dependent Qmax..... | 91 |
| B.3 | 60 Hz Dimension dependent Qmax..... | 92 |
| B.4 | 50 Hz Dimension dependent volume/pulse and batch..... | 94 |
| B.5 | 60 Hz Dimension dependent volume/pulse and batch..... | 95 |
| C | Control drawing..... | 97 |
| C.1 | Control drawing..... | 97 |
| | Index..... | 103 |

Introduction

1.1 Preface

These instructions contain all the information you need for using the device.


The instructions are aimed at persons mechanically installing the device, connecting it electrically, configuring the parameters and commissioning it, as well as service and maintenance engineers.

Note

It is the responsibility of the customer that the instructions and directions provided in the operating instructions are read, understood, and followed by the relevant personnel before installing the device.

1.2 Items supplied

- SITRANS F M MAG 6000 I or MAG 6000 I Ex de transmitter
- Wall mounting bracket (remote version)
- SITRANS F M literature CD containing software, certificates and device manuals
- Quick start guide



1.3 Revision history

The contents of these instructions are reviewed regularly and any corrections included in subsequent editions. We welcome all suggestions for improvement.

The following table lists the most important changes made to the documentation in the current and previous editions.

| Edition | Remarks | HW version | SW version |
|---------|---|------------|------------|
| 08/2018 | <ul style="list-style-type: none"> • Updated Safety Notes | 08 | 4.08 X06 |
| 04/2016 | <ul style="list-style-type: none"> • Various technical specifications updated • Control drawing updated | 08 | 4.08 X06 |


| Edition | Remarks | HW version | SW version |
|---------|--|------------|------------|
| 01/2015 | <ul style="list-style-type: none">• Graphics, technical data and factory settings changed to comprise:<ul style="list-style-type: none">– "BBL42" is displayed as the default setting in customer unit instead of "?". The unit can still be changed.– Improved minimum supply voltage for current output to 12 V.• Document revision identification changed according to new SIEMENS standard | 06 | 4.08 X06 |
| 09/2012 | <ul style="list-style-type: none">• Enhanced current output function• Updated menu functions; possibility of showing user defined units in display• Updated ATEX approval• General update | 06 | 4.07 X06 |
| 12/2011 | <ul style="list-style-type: none">• Updated ATEX approval• General update | 04 | 4.07 X06 |
| 03/2011 | <ul style="list-style-type: none">• First edition• Transmitter upgrade information included | 04 | 4.06 X06 |

1.4 Device identification

Inspection

1. Check for mechanical damage due to possible improper handling during shipment. All claims for damage are to be made promptly to the carrier.
2. Make sure the scope of delivery, and the information on the nameplate corresponds to the ordering information

Identification



- ① Code number
- ② Serial number
- ③ Power supply
- ④ Enclosure rating
- ⑤ MAWP (Maximum Allowable Working Pressure) at defined temperature, e.g. 25 °C
- ⑥ Fluid group statement required by PED
- ⑦ Communication module delivered with the flowmeter
- ⑧ Approvals
- ⑨ Media temperature

Figure 1-1 Example of MAG 6000 I Ex nameplate

1.5 Further Information

Product information on the Internet

The Operating Instructions are available on the documentation disk shipped with the device, and on the Internet on the Siemens homepage, where further information on the range of SITRANS F flowmeters may also be found:

Product information on the internet (<http://www.siemens.com/flowdocumentation>)


Worldwide contact person

If you need more information or have particular problems not covered sufficiently by these Operating Instructions, get in touch with your contact person. You can find contact information for your local contact person on the Internet:

Local contact person (http://www.automation.siemens.com/aspa_app/contactmenu.aspx?ci=yes®id=DEF&lang=en)

Safety notes

2.1 General safety instructions

| |
|--|
|  CAUTION |
| Correct, reliable operation of the product requires proper transport, storage, positioning and assembly as well as careful operation and maintenance. |
| Only qualified personnel should install or operate this instrument. |

Note

Alterations to the product, including opening or improper modifications of the product are not permitted.

If this requirement is not observed, the CE mark and the manufacturer's warranty will expire.

2.2 Laws and directives

General requirements

Installation of the equipment must comply with national regulations. For example EN 60079-14 for the European Community.

Instrument safety standards

The device has been tested at the factory, based on the safety requirements. In order to maintain this condition over the expected life of the device, the requirements described in these Operating Instructions must be observed.

Environmental conditions according to IEC61010-1:

- Indoor/Outdoor use
- Altitude up to 2000 m
- Maximum relative humidity 80% for temperatures up to 31°C (88 °F) decreasing linearly up to 50% relative humidity from 40 °C (104 °F)

2.3 Installation in hazardous area

- Overvoltage category II
- Pollution degree 2


| |
|--|
| NOTICE |
| Material compatibility |
| Siemens Flow Instruments can provide assistance with the selection of wetted sensor parts. However, the full responsibility for the selection rests with the customer and Siemens Flow Instruments can take no responsibility for any failure due to material incompatibility. |


CE marked equipment


The CE-mark symbolizes the compliance of the device with the following directives:

- EMC-directive 2004/108/EC
- Low voltage directive 2006/95/EC
- Pressure equipment directive (PED/DGRL) 97/23/EC
- ATEX Directive 94/9/EG

2.3 Installation in hazardous area

| |
|--|
|  WARNING |
| Conditions for safe use |
| Equipment used in hazardous areas must be Ex-approved and marked accordingly. It is required that the special conditions for safe use provided in the manual and in the Ex certificate are followed! |

| |
|--|
|  WARNING |
| Suitable hazardous area approval |
| Make sure the hazardous area approval is suitable for the environment in which the device will be installed. |

| |
|---|
|  WARNING |
| "Flameproof enclosure" type of protection |
| Only open devices with type of protection "Flameproof enclosure" in hazardous areas when the power to the device is turned off, otherwise there is a risk of explosion. |

⚠ WARNING**Laying of cables**

Cable for use in Zone 1 and 2 or 21 and 22 must satisfy the requirements for having a proof voltage > 500 V AC applied between the conductor/ground, conductor/shield and shield/ground.

Connect the devices that are operated in hazardous areas as per the stipulations applicable in the country of operation, e.g. for Ex "d" and "nA", permanent cables must be laid

⚠ WARNING**Requirements for meters used with transmitter**

With intrinsically safe circuits, use only certified meters appropriate for the transmitter.

If a non-conforming supply unit is used, the "fail-safe" type of protection will no longer be effective and the approval certification will be invalid.

2.3.1 ATEX 2 GD approval

The device is approved for use in hazardous area and has certificate Sira 11ATEX2124X.

Remote transmitter version:

Ⓔ II 2(1) GD

EX d e [ia] ia IIC T6 Gb


Ex tD A21 IP67 T85 °C

Ta -25 °C to 60 °C

Note**Markings for remote version only**


These markings are for the Remote version only; the marking applicable to the Compact versions depend upon their construction. See the latest issues of certificates Sira 07ATEX3181X, Sira 07ATEX1182X and Sira 03ATEX3339X.

2.3 Installation in hazardous area



Compact transmitter version:

- Ex d e [ia] ia IIC T3-T6 Gb
Ex tD A21 IP67 T** °C (** pipe temperature +13K, but not less than T85 °C)
(MAG 3100 / MAG 3100 P)
- Ex d e [ia] ia IIB T3-T6 Gb
Ex tD A21 IP67 T** °C (** pipe temperature +18K, but not less than T85 °C)
(MAG 1100 / MAG 1100 F)



For sensors:

Refer to sensor certificates:

MAG 3100 / MAG 3100 P: Sira 07ATEX1182X (DN 15-DN300); Sira 03ATEX3339X (DN350-DN2000)

MAG 1100 / MAG 1100 F: Sira 07ATEX3181X

Safety parameters associated with the remote transmitter version


Table 2-1 Intrinsically safe data

| Sensor electrode input (Terminals 0, 81, 82, 83, 84 - "ia circuits") | | |
|--|---------|---------|
| | IIB | IIC |
| U _o | 30 V DC | 30 V DC |
| I _o | 6.1 mA | 6.1 mA |
| C _o | 560 nF | 66 nF |
| L _o | 1 H | 0.96 H |
| P _o | 45.5 mW | 45.5 mW |

| Sensor coil terminals | Terminal type |
|-----------------------|---------------|
| 85 and 86 | "e" |

Power supply:

| Parameter | MAG 6000 I Ex de |
|---|--------------------------------|
| Supply | 115 to 230 VAC or 18 to 30 VDC |
| Max. allowable supply voltage U_m (according to ATEX certificate) | 264 V |
| Ambient temperature | -20 to +60 °C (-4 to 140 °F) |
| Enclosure | IP67 / NEMA 4X |

|  WARNING |
|---|
| Fail-safe protection |
| With intrinsically safe circuits, use only certified meters appropriate for the transmitter. |
| If a non-conforming supply unit is used, the "fail-safe" type of protection will no longer be effective and the approval certification will be invalid. |

User I/O interface

Remote MAG 6000 I: Model 7ME693-2BA4/5

Compact:

MAG 6000 I with MAG 3100 series: Model 7ME63x0-xxxxx-xD/E

| Passive current (31, 32) | | Active current (31, 32) | | | Relay (44, 45, 46) | | Frequency/pulse (56, 57) | | Profi (FISCO) (95, 96) | | Digital input (77, 78) | |
|--------------------------|------------|-------------------------|---------|---------|--------------------|-----------|--------------------------|------------|------------------------|-----------|------------------------|-----------|
| | IIC | | IIB | IIC | | IIC | | IIC | | IIC | | IIC |
| U_i | 28 V DC | U_o | 30 V DC | 30 V DC | U_i | 30 V DC | U_i | 28 V DC | U_i | 17.5 V DC | U_i | 30 V DC |
| I_i | 100 mA | I_o | 87.8 mA | 87.8 mA | I_i | 200 mA | I_i | 100 mA | I_i | 380 mA | I_i | |
| C_i | 19.7 nF | C_o | 557 nF | 63 nF | C_i | 3.3 nF | C_i | 14.2 nF | C_i | 0 nF | C_i | 0 nF |
| L_i | 36 μ H | L_o | 18.4 mH | 4.6 mH | L_i | 0 μ H | L_i | 36 μ H | L_i | 0 μ H | L_i | 0 μ H |
| P_i | 0.7 W | P_o | 0.66 W | 0.61 W | P_i | 1.2 W | P_i | 1.2 W | P_i | 5.32 W | P_i | 1.2 W |


Special conditions for ATEX 2 GD

It is required that:

- The equipment is supplied with its current output (terminals 31 and 32) in "Passive mode only".
- The external connections to terminals 85 and 86 shall comply with the following:
 - The wire conductors shall have a cross-sectional area between 0.5 mm² and 2.5 mm².
 - No more than one single or multiple strand wire conductor shall normally be connected to each of the terminals. If multiple conductors are required, these shall be joined in a suitable manner, e.g. two conductors into a single insulated crimped boot lace ferrule.
 - The insulation on the wire conductors shall extend to within 1 mm of the metal of the terminal throat.
 - The terminal screws shall be tightened down with a torque between 0.4 Nm and 0.45 Nm.
- The equipment shall not be opened when an explosive gas or dust atmosphere may be present.
- The equipment internal circuits at the following terminals are not capable of withstanding a 500 V r.m.s. a.c. test to earth as required by clause 6.3.12 of EN 60079-11-2007. This must be taken into account in any equipment installation:
 - Terminals 77 and 78 – Digital input.
 - Terminals 95 and 96 – Foundation Fieldbus/Profibus (FISCO). (Not applicable to Model 7ME693-2BA6)
 - Terminals 0, 81, 82, 83 and 84 – Sensor electrode input (Remote Version only).
- electrical connections are in accordance with national requirements for installation of electrical systems in hazardous areas, e.g. EN60079-14 in Europe.
- the protective cover for the power terminals is properly installed.
When the device is de-energized, the power supply terminal room may be opened because the non-intrinsically safe power terminals are separately covered. Only remove protective cover when device is de-energized.
- sensor and transmitter are connected to the potential equalizing conductor.
- when protective earth (PE) is connected, no potential difference between the protective earth (PE) and the potential equalization (PA) can exist, even during a fault condition.

2.3.2 FM/CSA Class I, Zone 1 approval

Compact and remote versions



User I/O interface

Remote MAG 6000 I: Model 7ME693-2BA4/5

Compact:

MAG 6000 I with MAG 1100: Model 7ME6110-xxx2x-xD/E


MAG 6000 I with MAG 1100 F: Model 7ME6140-xxx2x-xD/E

MAG 6000 I with MAG 3100 series: Model 7ME63x0-xxxxx-xD/E

| Passive current (31, 32) | | Active current (31, 32) | | | Relay (44, 45, 46) | | Frequency/pulse (56, 57) | | Profii (FISCO) (95, 96) | | Digital input (77, 78) | |
|-----------------------------|------------|----------------------------|---------|---------|-----------------------|-----------|-----------------------------|------------|----------------------------|-----------|---------------------------|-----------|
| | IIB/IIC | | IIB | IIC | | IIB/IIC | | IIB/IIC | | IIB/IIC | | IIB/IIC |
| U_i | 28 V DC | U_o | 30 V DC | 30 V DC | U_i | 30 V DC | U_i | 28 V DC | U_i | 17.5 V DC | U_i | 30 V DC |
| I_i | 100 mA | I_o | 87.8 mA | 87.8 mA | I_i | 200 mA | I_i | 100 mA | I_i | 380 mA | I_i | |
| C_i | 19.7 nF | C_o | 557 nF | 63 nF | C_i | 7.5 nF | C_i | 14.2 nF | C_i | 0 nF | C_i | 0 nF |
| L_i | 36 μ H | L_o | 18.4 mH | 4.6 mH | L_i | 0 μ H | L_i | 36 μ H | L_i | 0 μ H | L_i | 0 μ H |
| P_i | 0.7 W | P_o | 0.66 W | 0.61 W | P_i | 1.2 W | P_i | 1.2 W | P_i | 5.32 W | P_i | 1.2 W |

2.3.3 FM Class I, II, III, Div 1 approval

Compact version for MAG 3100/3100 P sensors DN 15 to 300 (½" to 12")



Hazardous area

Class I, Div. 1, Group A, B, C, D

User I/O interface

| Passive current (31, 32) | | Active current (31, 32) | | | Relay (44, 45, 46) | | Frequency/pulse (56, 57) | | Profii (FISCO) (95, 96) | | Digital input (77, 78) | |
|-----------------------------|---------|----------------------------|---------|---------|-----------------------|---------|-----------------------------|---------|----------------------------|-----------|---------------------------|---------|
| | ABCD | | CD | AB | | ABCD | | ABCD | | ABCD | | ABCD |
| U_i | 28 V DC | U_o | 30 V DC | 30 V DC | U_i | 30 V DC | U_i | 28 V DC | U_i | 17.5 V DC | U_i | 30 V DC |
| I_i | 100 mA | I_o | 87.8 mA | 86.8 mA | I_i | 200 mA | I_i | 100 mA | I_i | 380 mA | I_i | |
| C_i | 19.7 nF | C_o | 557 nF | 63 nF | C_i | 3.3 nF | C_i | 14.2 nF | C_i | 0 nF | C_i | 0 nF |
| L_i | 36 μH | L_o | 18.4 mH | 4.6 mH | L_i | 0 μH | L_i | 36 μH | L_i | 0 μH | L_i | 0 μH |
| P_i | 0.7 W | P_o | 0.66 W | 0.66 W | P_i | 1.2 W | P_i | 1.2 W | P_i | 5.32 W | P_i | 1.2 W |

Notes from control drawing

1. The non-intrinsically safe terminals (power rail) must not be connected to a device which uses or generates more than 250/30 Vrms or DC.
2. The installation must meet the requirements of the National Electrical Code/Canadian Electrical Code.
3. Conduit seal is required within 460 mm (18") from MAG 6000 I in hazardous areas (Class I, Div. 1).

The control drawings are found on the CD-ROM shipped with the device and on the Siemens homepage at <http://www.siemens.com/flowdocumentation>.

See also

Control drawing (Page 97)


Description

3.1 Applications

The pulsed DC-powered magnetic flowmeters are suitable for measuring the flow of almost all electrically conductive liquids, pastes, and slurries with max. 40% solids.

The main applications can be found in the following sectors:

- Water and waste water
- Chemical and pharmaceutical industries
- Food & beverage industry
- Mining and cements industries
- Pulp and paper industry
- Steel industry
- Power generation; utility and chilled water industry

| |
|--|
|  WARNING |
| <p>This is a Class A product</p> <p>In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.</p> |

3.2 System components

The SITRANS F M flowmeter system includes:

- Transmitter (types: MAG 6000 I standard or Ex version in compact or remote configuration)
- Sensor (types: SITRANS F M MAG 1100/1100 HT/1100F, MAG 5100 W, MAG 3100 P/3100 or 3100 HT)
- Communication module (optional) (types: HART, PROFIBUS PA/DP, MODBUS RTU RS485, Foundation Fieldbus H1, Devicenet)

Communication solutions

The SITRANS F M platform enables fitting of add-on bus modules without loss of analog, pulse and relay outputs, and all modules can be fitted as true Plug & Play.

Standard transmitter:

- HART
- PROFIBUS PA and DP

- Foundation Fieldbus H1
- MODBUS RTU RS485
- Devicenet

Ex-transmitter:

- HART
- PROFIBUS PA
- Foundation Fieldbus H1

3.3 Design

The SITRANS F M MAG 6000 I/MAG 6000 I Ex de transmitter is designed for demands in the process industry. The robust cast aluminum housing provides superb protection, even in the most harsh industrial environments. Full input and output functionality is given even in the Ex version.



Compact version



Remote version

The transmitter is designed for either compact or remote installation in non-hazardous or hazardous areas.

Functions:


- Flow rate measurement
- 2 measuring ranges
- Display with 2 totalizers and keypad
- Low flow cut-off
- Analog, pulse/frequency and relay outputs
- Optional: additional digital communication modules
- Error and error log system
- Uni-/bidirectional flow
- Limit switches
- Integrated batch control

3.4 Features

- SENSORPROM® memory unit
 - All SITRANS F M electromagnetic flowmeters feature a unique SENSORPROM® memory unit which stores sensor calibration data as well as transmitter settings for the lifetime of the product.
 - At commissioning the flowmeter commences measurement without any initial programming.
 - The factory settings matching the sensor are stored in the SENSORPROM® unit. Also customer- specified settings are downloaded to the SENSORPROM® unit. Should the transmitter be replaced, the new transmitter will upload all previous settings and resume measurement without any need for re-programming.
- USM II "Plug & Play" add-on communication modules
USM II - the Universal Signal Module with "Plug & Play" simplicity makes it easy to access and integrate the flow measurement with almost any control system. It ensures the flowmeter will be easy to upgrade to new communication platforms in the future, too.
- CAN communication
The transmitter operates internally via an internal CAN communication bus. Signals are transferred through a signal conditioner to the display module and to/from internal/external option modules and the dialog module.
- Dialog module
The display unit consists of a 3-line display and a 6-key keypad. The display shows a flow rate or a totalizer value as a primary reading and can be changed from the factory-set English to ten other languages. In the Operator menu setup it is possible to configure the display to show various different menus.
- Output module
The output module converts flow data to analog, digital and relay outputs. The outputs are galvanically isolated and can be individually set to suit a particular application.

3.5 Theory of operation

The flow measuring principle is based on Faraday's law of electromagnetic induction.



3.5 Theory of operation

U_i = When an electrical conductor of length L is moved at velocity v , perpendicular to the lines of flux through a magnetic field of strength B , the voltage U_i is induced at the ends of the conductor

$$U_i = L \times B \times v$$

- U_i = Induced voltage
- L = Conductor length = Inner pipe diameter = k_1
- B = Magnetic field strength = k_2
- v = Velocity of conductor (media)
- $k = k_1 \times k_2$

$U_i = k \times v$, the electrode signal is directly proportional to the fluid velocity


Coil current module generates a pulsating magnetizing current that drives the coils in the sensor. The current is permanently monitored and corrected. Errors or cable faults are registered by the self-monitoring circuit.

Input circuit amplifies the flow-proportional induced signal from the electrodes. The input impedance is extremely high: $>10^{14} \Omega$ which allows flow measurements on fluids with conductivities as low as $5 \mu\text{S/cm}$. Measuring errors due to cable capacitance are eliminated due to active cable screening.

Digital signal processor converts the analog flow signal to a digital signal and suppresses electrode noise through a digital filter. Inaccuracies in the transmitter as a result of long-term drift and temperature drift are monitored and continuously compensated for via the self-monitoring circuit. The analog to digital conversion takes place in an ultra low noise ASIC with 23 bit signal resolution. This has eliminated the need for range switching. The dynamic range of the transmitter is therefore unsurpassed with a turn down ratio of minimum 3000:1.

Installing/Mounting

This chapter describes how to install the flowmeter in the compact version as well as in the remote version.



SITRANS F flowmeters with minimum IP67/NEMA 4X enclosure rating are suitable for indoor and outdoor installations.


All sensors have an associated SENSORPROM® containing all necessary sensor data.

4.1 Installation safety precautions

| | |
|---|----------------|
| | WARNING |
| High pressure hazard | |
| In applications with working pressures/media that can be dangerous to people, surroundings, equipment or others in case of pipe fracture, we recommend that special precautions such as special placement, shielding or installation of a pressure guard or a safety valve are taken when the flowmeter is mounted. | |

4.2 Installation conditions

As the transmitter housing and the display can be oriented in all directions, reading and operating the flowmeter is possible under almost any installation conditions.



To ensure optimum flow measurement, attention should be paid to the following:

4.3 Compact installation

Vibrations




Figure 4-1 Avoid strong vibrations

In installation with strong vibrations remote installation of the transmitter is recommended.

4.3 Compact installation

The flowmeter is delivered with default factory settings and start measuring the flow rate after power-up. The SENSORPROM® is factory-mounted in the transmitter.




Figure 4-2 Compact installation

Note

To avoid too high tension on small sizes MAG 1100 sensors, transmitter must be supported.

4.4 Remote installation

For remote versions the SENSORPROM® has to be removed from the sensor terminal box and mounted in the remote transmitter.






Figure 4-3 Remote installation

Cable length and type (as described in Cable requirements (Page 72)) must be used. For installation conditions for sensors, see respective sensor operating instructions.

1. Remove sensor terminal box lid.




2. Remove SENSORPROM® unit from sensor terminal box.



4.4 Remote installation

- 3. Mount SENSORPROM® in remote transmitter.




- 4. Fit M20 or ½" NPT cable glands on sensor terminal box.
- 5. Fit and connect electrode and coil cables as described in Connecting (Page 31).

Note

Unscreened cable ends must be kept as short as possible.

Electrode cable and coil cable must be kept separate to prevent interference.

- 6. Tighten cable glands and lid screws well to obtain optimum sealing.



| |
|--|
|  WARNING |
| Mount terminal box lid before power up. |

4.4.1 Wall mounting using standard mounting plate

1. Fit the mounting plate on the transmitter using the mounting material provided
2. Mount transmitter with mounting plate on the wall.




Figure 4-4 Standard mounting plate

For details on mounting plate, see Dimensions and weight (Page 67).

Note

The standard mounting plate is only suitable for wall mounting.

4.4.2 Pipe or wall mounting with assembly bracket


Optional pipe or wall mounting assembly bracket

Note

The assembly bracket is not part of the standard delivery and must be ordered separately.

Pipe mounting

1. Mount the assembly bracket on the pipe using the fastening brackets
2. Fasten the transmitter with the two screws provided.




Pipe mounting with assembly bracket

Wall mounting

1. Fasten the assembly bracket to the back of the transmitter
2. Fasten the transmitter and assembly bracket to the wall

Note


The fastening brackets and nuts are not needed for wall mounting.



Wall mounting with assembly bracket. Dimensions in mm (inch).

This chapter describes how to wire up the device without bus communication.

In order to wire up devices with communication modules, e.g. HART, Profibus PA or DP, Foundation Fieldbus, DeviceNet or MODBUS, refer to the Operating Instructions for relevant add-on module.



- ① Magnetic coil cable to sensor
- ② Terminal box for power supply and output signal cables
- ③ Potential equalization
- ④ Output signal cable
- ⑤ Power supply
- ⑥ Electrode cable to sensor
- ⑦ Terminal box for magnetic coil and electrode cables

Figure 5-1 Overview, Electrical connections

Cable specifications

- Only use cables with at least the same degree of protection as the sensor to install the sensor.
- The cable length from the cable gland to the terminals must be kept as short as possible. Cable loops in the terminal box must be avoided.
- To guarantee the IP 67/NEMA 4 degree of protection, use cables with external diameters matching the used cable glands.

5.1 Safety precautions

 **WARNING**

Mains supply from building installation Overvoltage category II

A fused (max. 16 A) circuit breaker must be installed in close proximity to the equipment and within easy reach of the operator. It must be marked as the disconnecting device for the equipment.

 **WARNING**

Field wiring installation

Ensure that the national regulations of the country in which the devices are installed are met.

 **WARNING**

Qualified personnel

Only qualified personnel may carry out work on the electrical connections.

 **WARNING**

Use in hazardous areas

Before opening the terminal box check that:

- No explosion hazard exists
- A fire department permission certificate has been issued
- All connection leads are potential free

Special requirements apply to the location and interconnection of sensor and transmitter. See "Installation in hazardous area"

 **WARNING**

Maximum short circuit current

Only connect the device to a power supply which has a potential short circuit current equal or below of 35 A.


 **WARNING**

Danger of electric shock

Do **not** power up when lid is open.

Do **not** open lid while power is on, unless operating in an Ex ia environment.

5.2 Electrical connection



Electrical connection label

The electrical connection label is placed in the lid of the terminal box.

| Non-Ex version | | | Ex version | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----------|--|---|--|--|------------|-----------|--------------|-------|-----|-------|-------|-----|--|--|-----|--------|----|--|---------------------|----|---|--------------------------|----|----|--|----|----|----|-----|----|--|------------------------|----|---|--------------------|----|---|--------------------------|----|--|--|----|----|---------------------------|----|---|----|---|----|----|----|---|---------------------------------------|----|---|--|----|--|---------------|----------------------|--|--|---|--|--|---|--|--|-----------------------|--|--|-----------------------|------------|-----------|--------------|--|-------|-----|-------|---------|-------|-----|--|--|--|-----|--------|--|----|--|---------------------|--------------------------|----|---|--|---|----|----|--------------|------------------|----|----|-------------------|----|-----|------|----|--|------------------------|------------------|----|---|--------------------|----------------------------|----|---|--------------------------|-----------------------|----|--|--|------|----|----|---------------------------|--|----|---|----|---|----|----|----|---|---------------------------------------|--------------------|----|---|--|----------------|----|--|---------------|------|----------------------|--|--|--|---|--|--|--|
| <table border="1"> <thead> <tr> <th colspan="3">Electrical Connection</th> </tr> <tr> <th>Terminals:</th> <th>Function:</th> <th>Description:</th> </tr> </thead> <tbody> <tr> <td>L (1)</td> <td>L/+</td> <td>AC/DC</td> </tr> <tr> <td>N (2)</td> <td>N/-</td> <td></td> </tr> <tr> <td></td> <td>Gnd</td> <td>Ground</td> </tr> <tr> <td>31</td> <td></td> <td>Current output HART</td> </tr> <tr> <td>32</td> <td>-</td> <td>RL<500 Ohm, HART>230 Ohm</td> </tr> <tr> <td>44</td> <td>NO</td> <td rowspan="3">Relay output AC 42V / 2A DC 24V / 1A</td> </tr> <tr> <td>45</td> <td>NC</td> </tr> <tr> <td>46</td> <td>COM</td> </tr> <tr> <td>56</td> <td></td> <td>DC 3-30V Max. 100mA</td> </tr> <tr> <td>57</td> <td>-</td> <td>200 Ohm<Ri<10 Kohm</td> </tr> <tr> <td>77</td> <td>-</td> <td>DC 11-30V Ri 4.4 Kohm</td> </tr> <tr> <td>78</td> <td></td> <td></td> </tr> <tr> <td>91</td> <td>T1</td> <td rowspan="4">Profibus DP Modbus RTU</td> </tr> <tr> <td>92</td> <td>B</td> </tr> <tr> <td>93</td> <td>A</td> </tr> <tr> <td>94</td> <td>T2</td> </tr> <tr> <td>95</td> <td>1</td> <td>Profibus PA Foundation Fieldbus</td> </tr> <tr> <td>96</td> <td>2</td> <td></td> </tr> <tr> <td>97</td> <td></td> <td>Not connected</td> </tr> <tr> <td colspan="3"> Shield for BUS Comm. </td> </tr> <tr> <td colspan="3"> I-OUT ACTIVE <input type="checkbox"/> Modul addr.: _____ ① I-OUT PASSIVE <input type="checkbox"/> FW revision: _____ ② <small>X indicates factory default setting</small> </td> </tr> </tbody> </table> | | | Electrical Connection | | | Terminals: | Function: | Description: | L (1) | L/+ | AC/DC | N (2) | N/- | | | Gnd | Ground | 31 | | Current output HART | 32 | - | RL<500 Ohm, HART>230 Ohm | 44 | NO | Relay output AC 42V / 2A DC 24V / 1A | 45 | NC | 46 | COM | 56 | | DC 3-30V Max. 100mA | 57 | - | 200 Ohm<Ri<10 Kohm | 77 | - | DC 11-30V Ri 4.4 Kohm | 78 | | | 91 | T1 | Profibus DP Modbus RTU | 92 | B | 93 | A | 94 | T2 | 95 | 1 | Profibus PA Foundation Fieldbus | 96 | 2 | | 97 | | Not connected | Shield for BUS Comm. | | | I-OUT ACTIVE <input type="checkbox"/> Modul addr.: _____ ① I-OUT PASSIVE <input type="checkbox"/> FW revision: _____ ② <small>X indicates factory default setting</small> | | | <table border="1"> <thead> <tr> <th colspan="3">Electrical Connection</th> <th>Approval: 11ATEX2124X</th> </tr> <tr> <th>Terminals:</th> <th>Function:</th> <th>Description:</th> <th></th> </tr> </thead> <tbody> <tr> <td>L (1)</td> <td>L/+</td> <td>AC/DC</td> <td>Um=264V</td> </tr> <tr> <td>N (2)</td> <td>N/-</td> <td></td> <td></td> </tr> <tr> <td></td> <td>Gnd</td> <td>Ground</td> <td></td> </tr> <tr> <td>31</td> <td></td> <td>Current output HART</td> <td>RL<500 Ohm, HART>230 Ohm</td> </tr> <tr> <td>32</td> <td>-</td> <td></td> <td>Active: Uo=28V, Io=87mA Passive: Ui=30V/DC, Ii=100mA</td> </tr> <tr> <td>44</td> <td>NO</td> <td rowspan="3">Relay output</td> <td>Ui=30V, Ii=200mA</td> </tr> <tr> <td>45</td> <td>NC</td> <td>Pi=1.2W, Ci=7.5nF</td> </tr> <tr> <td>46</td> <td>COM</td> <td>Li=0</td> </tr> <tr> <td>56</td> <td></td> <td>DC 3-30V Max. 100mA</td> <td>Ui=28V, Ii=100mA</td> </tr> <tr> <td>57</td> <td>-</td> <td>200 Ohm<Ri<10 Kohm</td> <td>Pi=1.2W, Ci=11nF, Li=34 µH</td> </tr> <tr> <td>77</td> <td>-</td> <td>DC 11-30V Ri 4.4 Kohm</td> <td>Ui=30V, Pi=1.2W, Ci=0</td> </tr> <tr> <td>78</td> <td></td> <td></td> <td>Li=0</td> </tr> <tr> <td>91</td> <td>T1</td> <td rowspan="4">Profibus DP Modbus RTU</td> <td></td> </tr> <tr> <td>92</td> <td>B</td> </tr> <tr> <td>93</td> <td>A</td> </tr> <tr> <td>94</td> <td>T2</td> </tr> <tr> <td>95</td> <td>1</td> <td>Profibus PA Foundation Fieldbus</td> <td>Ui=17.5V, Ii=380mA</td> </tr> <tr> <td>96</td> <td>2</td> <td></td> <td>Pi=5.32W, Ci=0</td> </tr> <tr> <td>97</td> <td></td> <td>Not connected</td> <td>Li=0</td> </tr> <tr> <td colspan="3"> Shield for BUS Comm. </td> <td></td> </tr> <tr> <td colspan="3"> I-OUT ACTIVE <input type="checkbox"/> Modul addr.: _____ ① I-OUT PASSIVE <input type="checkbox"/> FW revision: _____ ② <small>X indicates factory default setting</small> </td> <td></td> </tr> </tbody> </table> | | | Electrical Connection | | | Approval: 11ATEX2124X | Terminals: | Function: | Description: | | L (1) | L/+ | AC/DC | Um=264V | N (2) | N/- | | | | Gnd | Ground | | 31 | | Current output HART | RL<500 Ohm, HART>230 Ohm | 32 | - | | Active: Uo=28V, Io=87mA Passive: Ui=30V/DC, Ii=100mA | 44 | NO | Relay output | Ui=30V, Ii=200mA | 45 | NC | Pi=1.2W, Ci=7.5nF | 46 | COM | Li=0 | 56 | | DC 3-30V Max. 100mA | Ui=28V, Ii=100mA | 57 | - | 200 Ohm<Ri<10 Kohm | Pi=1.2W, Ci=11nF, Li=34 µH | 77 | - | DC 11-30V Ri 4.4 Kohm | Ui=30V, Pi=1.2W, Ci=0 | 78 | | | Li=0 | 91 | T1 | Profibus DP Modbus RTU | | 92 | B | 93 | A | 94 | T2 | 95 | 1 | Profibus PA Foundation Fieldbus | Ui=17.5V, Ii=380mA | 96 | 2 | | Pi=5.32W, Ci=0 | 97 | | Not connected | Li=0 | Shield for BUS Comm. | | | | I-OUT ACTIVE <input type="checkbox"/> Modul addr.: _____ ① I-OUT PASSIVE <input type="checkbox"/> FW revision: _____ ② <small>X indicates factory default setting</small> | | | |
| Electrical Connection | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminals: | Function: | Description: | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L (1) | L/+ | AC/DC | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N (2) | N/- | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Gnd | Ground | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | | Current output HART | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 32 | - | RL<500 Ohm, HART>230 Ohm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 44 | NO | Relay output AC 42V / 2A DC 24V / 1A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 | NC | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 46 | COM | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 56 | | DC 3-30V Max. 100mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 57 | - | 200 Ohm<Ri<10 Kohm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 77 | - | DC 11-30V Ri 4.4 Kohm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 78 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 91 | T1 | Profibus DP Modbus RTU | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 92 | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 93 | A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 94 | T2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 95 | 1 | Profibus PA Foundation Fieldbus | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 96 | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 97 | | Not connected | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Shield for BUS Comm. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| I-OUT ACTIVE <input type="checkbox"/> Modul addr.: _____ ① I-OUT PASSIVE <input type="checkbox"/> FW revision: _____ ② <small>X indicates factory default setting</small> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Electrical Connection | | | Approval: 11ATEX2124X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Terminals: | Function: | Description: | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L (1) | L/+ | AC/DC | Um=264V | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N (2) | N/- | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Gnd | Ground | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31 | | Current output HART | RL<500 Ohm, HART>230 Ohm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 32 | - | | Active: Uo=28V, Io=87mA Passive: Ui=30V/DC, Ii=100mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 44 | NO | Relay output | Ui=30V, Ii=200mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 45 | NC | | Pi=1.2W, Ci=7.5nF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 46 | COM | | Li=0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 56 | | DC 3-30V Max. 100mA | Ui=28V, Ii=100mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 57 | - | 200 Ohm<Ri<10 Kohm | Pi=1.2W, Ci=11nF, Li=34 µH | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 77 | - | DC 11-30V Ri 4.4 Kohm | Ui=30V, Pi=1.2W, Ci=0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 78 | | | Li=0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 91 | T1 | Profibus DP Modbus RTU | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 92 | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 93 | A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 94 | T2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 95 | 1 | Profibus PA Foundation Fieldbus | Ui=17.5V, Ii=380mA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 96 | 2 | | Pi=5.32W, Ci=0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 97 | | Not connected | Li=0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Shield for BUS Comm. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| I-OUT ACTIVE <input type="checkbox"/> Modul addr.: _____ ① I-OUT PASSIVE <input type="checkbox"/> FW revision: _____ ② <small>X indicates factory default setting</small> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ① Fill in the address of the used communication module after installation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ② Fill in the new FW and HW revisions in case spare part exchange | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Note

Min. 4 mm² is only required for ATEX 2 GD and FM/CSA Class I, Zone 1/21 installations.

Note

Terminals 81 and 84 are only to be connected if special electrode cable with double screening is used, e.g. when empty pipe function or long cables are used.

Note

Special cable with individual wire shields (shown as dotted lines) are only required when using empty pipe function or long cables.

Note

All inputs and outputs are galvanically isolated PELV circuits with 60 VDC isolation from each other and ground. Exception are sensor connections that are connected to ground.

| | |
|---|----------------|
| | WARNING |
| Grounding | |
| The mains protective earth wire must be connected to the PE terminal in accordance with the diagram (Protection class I). | |

NOTICE**HART communication**


HART communication on active current output could be disturbed during operation in areas with a high frequency electromagnetic field

NOTICE**Output cables**

If long cables are used in noisy environments, it is recommended to use screened cables.

NOTICE**Electrode cables**

Dotted connections are only to be made when using special electrode cables.

Active/passive current output

| Pos | Active/Passive | Factory default |
|-----|----------------|-----------------------|
| A | Active | MAG 6000 I |
| B | Passive | MAG 6000 I Ex version |

Note

For Ex versions active or passive current output is preselected at ordering and cannot be changed.

Non-Ex versions can be connected as either active or passive.

Note

The factory default setting for the current output is marked by an "X" and can be found on a label on the back of the lid.

5.3 Connection of sensor and transmitter in remote version




Figure 5-2 Example of label inside the lid

5.3 Connection of sensor and transmitter in remote version


The following contains a short description of how to connect the sensor to the transmitter SITRANS F M MAG 6000 I. For more information refer to the Operating Instructions for the respective sensor.

Check that the serial numbers on the sensor and the SENSORPROM® unit are identical.


| |
|---|
| <p>⚠ WARNING</p> <p>Danger of electric shock</p> <p>Do not power up when lid is open.</p> <p>Do not open lid while power is on, unless operating in an Ex ia environment.</p> |
|---|

5.3 Connection of sensor and transmitter in remote version

1. Relocate SENSORPROM® memory unit from sensor to transmitter terminal block.




2. Fit coil and electrode cables through cable glands in sensor terminal box.




3. Connect signal and coil cables to transmitter as follows:


5.3 Connection of sensor and transmitter in remote version



- Remove cover for connection board.
- Remove protection plate for connectors
- Remove the two connectors.
- Mount the two cables through the two cable glands and mount connectors on coil and electrode cables.
- Mount the two connectors on connection board; fit protection plate and fasten bolt.



1. Tighten all cable glands on sensor and transmitter to obtain optimum sealing.
2. Mount cover for connection board and mount lid on sensor.



3. Transmitter is ready to be powered up.

| NOTICE |
|---|
| Avoid exposing transmitter to direct sunlight Exposing the transmitter to direct sunlight may increase the operating temperature above its specified limit, and decrease display visibility. In such case, protect the transmitter from direct sunlight. |


5.4 Wiring in hazardous area

Hazardous area applications


Special requirements apply to the location and interconnection of sensor and transmitter. See "Installation in hazardous area (Page 12)"

The following shows how to connect the device in various applications.

Current output in passive and active modes



Frequency/pulse output in passive mode



5.5 Connection of bus communication add-on modules


When the add-on module has been installed, the electrical connections are available on terminal rows 91-97.

For more information


Refer to the relevant BUS communication Quick Start or Operating Instructions available at the SITRANS F literature CD or on the internet, at: www.siemens.com/flowdocumentation (www.siemens.com/flowdocumentation)

5.6 Reassembling the device

Ensure that the two screws (20 TORX) are tightened properly for correct assembly and proper ground connection.



Ensure sufficient insulation by covering power supply terminals with plastic cover. Fasten the plastic cover with two screws.



Commissioning

In this chapter it is described how to commission the device via the local user interface (LUI).

The display is described in details in section Local user interface (Page 41).

Furthermore, the following functions are described in details:

- Changing password (Page 43)
- Changing basic settings (Page 44)
- Changing operator menu setup (Page 47)
- Changing language (Page 48)

Detailed diagrams concerning the specific menu are shown in appendix menu diagrams (Page 75).

For factory settings, see Factory settings (Page 89).

6.1 Local user interface

With the capacitive touch keypad the device can be operated without opening the lid. An LED light gives feedback on accepted command.




Figure 6-1 Local user interface




Figure 6-2 Capacitive touch keypad

Note

Isolate the device from power when removing the glass lid

If the glass lid is rotated during operation, the capacitive touch keypad automatically calibrates to align the distance from lid to keypad. To avoid any unintended programming during this calibration procedure, it is recommended to always isolate the device from power before removing the glass lid and until it is properly fixed to the device again.

Mode field symbols

| | | | | | |
|--|--------------------|--|----------------|--|------------------------|
| | Communication mode | | Language mode | | Sensor characteristics |
| | Service mode | | Basic settings | | Reset mode |
| | Operator menu | | Output | | Operator-active |
| | Product identity | | External input | | Operator-inactive |





Lock field symbols

| | | | |
|--|------------------|--|--|
| | Ready for change | | Access to submenu |
| | Value locked | | RESET MODE: Zero setting of totalizers and initialization of setting |

Keypad

The keypad is used to set the flowmeter. The keys function as follows:



- TOP UP KEY This key (when held for 2 sec.) is used to switch between operator menu and setup menu. In transmitter setup menu, a short press will cause a return to previous level.
- FORWARD KEY This key is used to step forward through the menus. It is the only key normally used by the operator.

| | | |
|-----------------|---|---|
| BACKWARD KEY |  | This key is used to step backwards through the menus. |
| CHANGE KEY |  | With this key settings or numerical values are changed. |
| SELECT KEY |  | With this key figures to be changed are selected. |
| LOCK/UNLOCK KEY |  | This key enables the operator to change settings and it gives access to submenus. |


6.2 Menu structure

The menu is built up of two parts. An **operator menu** and a **setup menu**, see also Menu diagrams (Page 75).

Operator menu

The operator menu is for daily operation. It can be customized in the operator menu setup in which the menus that are to be available to the operator are selected. The transmitter always starts up in operator menu No. 1. The forward  and the backward keys  are used to step through the operator menus.



Setup menu

The setup menu is for commissioning and service only. Access to the setup menu is gained by pressing the top up key  for 2 seconds. The setup menu operates in two modes:

- View mode
- Setup mode

View mode is a read-only mode. The pre-selected settings can only be scanned.





Setup mode is a read and write mode. The pre-selected settings can be scanned and changed. Access to the setup mode is password-protected. The factory set password is 1000.





Access to a submenu in the setup menu is gained by pressing the lock key . Press the top up key  briefly to return to the previous menu. Press longer (2 sec.) to exit the setup menu and return to operator menu no. 1.


6.3 Changing password

The setup menu is password-protected in order to ensure that only authorized personnel can make any changes in transmitter settings.

Change password as follows:



1. Press top up key  for 2 sec.
2. Enter password.
3. Use forward key  or backward key  to reach password menu.
4. Press lock/unlock key  to unlock password.

5. Use select key  and change key  to change password.
6. Press lock/unlock key  to confirm new password.
7. Press top up key  two times to exit setup mode.



The factory-set password is 1000, but it can be changed to any value between 1000 and 9999.

Factory setting of password can be re-established as follows:

1. Switch off power supply.
2. While pressing top up key  - switch on power supply.
3. Release top up key  after 10 sec.

6.4 Changing basic settings

In the basic settings menu it is possible to set the following parameters:

| Parameter | Description |
|--------------------|---|
| Main frequency | Selection of main power supply frequency corresponding to the country in which the flowmeter is installed (e.g. 60 Hz in America). |
| Flow direction | Selection of correct flow direction in pipe. |
| Customer units | Setting of user defined volume and time units. |
| Q _{max} | Setting of measuring range, analog outputs and frequency output. Also individual dimension-dependent setting of value, decimal point, unit and time. |
| Q _{max} 2 | Setting of measuring range, analog outputs and frequency output. Also individual dimension-dependent setting of value, decimal point, unit and time. This menu is only visible if chosen as external digital input. |
| Totalizer | Setting of unit and decimal point. |
| Low flow cut-off | Setting of a percentage of selected Q _{max} . This filters noise in installation reducing fluctuations in display and all outputs. |
| Empty pipe cut-off | When set to "On" the alarm will indicate when sensor is running empty. All readings, display and outputs, will indicate zero. |
| Velocity unit | Setting of velocity unit per time unit |
| Error level | Selecting error level at which flowmeter will detect an error. |










Note

Totalizer 2 is not visible when batch is selected as digital output.


Note


Q_{\max} 2 is visible only when chosen as digital input.

Change basic settings as follows:

1. Press top up key  for 2 sec.
2. Enter password.
3. Use forward key  to reach basic settings menu.
4. Press lock/unlock key  to unlock settings.
5. Use forward key  or backward key  to reach relevant menu.
6. Press lock/unlock key  to unlock settings.
7. Use select key  and change key  to change settings.
8. Press lock/unlock key  to confirm new settings.



6.4 Changing basic settings

9. Repeat steps 5-8 to change other settings.
10. Press top up key  two times to exit setup mode.





Decimal point can be positioned and units set individually for flow rate in totalizer 1 and totalizer 2.

Changing decimal point position

1. Enter the respective totalizer menu.
2. Use select key  to position cursor below decimal point.
3. Use change key  to move decimal point to requested position.

Changing units




1. Use select key  to position cursor below unit.
2. Press change key  until requested unit is displayed.

6.5 Changing operator menu setup




In the operator menu the menus required for daily operation of the flowmeter are shown. It is possible to hide and change some of the menus in the operator menu. This is done in the operator menu setup menu, see diagram Operator menu setup (Page 86).

Customizing menus in operator menu

To customize the menus in the operator menu perform the following steps:

1. Press top up key  for 2 sec.
2. Enter password.
3. Use forward key  or backward key  to reach operator menu.







Changing text in line 1

1. Press lock/unlock key  to unlock setting.
2. Use change key  to select desired text.
3. Press lock/unlock key  to confirm selected text.



Note

If "Text" is selected in line 2, this line functions as a heading for the value shown in line 3. Otherwise it shows the actual value of the reading selected.






Enabling two readings

1. Use forward key  to reach requested menu.
2. Press lock/unlock key  to unlock setting.
3. Use select key  to move cursor to upper line.
4. Use change key  to select requested reading.
5. Press lock/unlock key  to confirm selection.
6. Use select key  to move cursor to line 3.

6.6 Changing language

7. Use change key  to select desired setting.
8. Press lock/unlock key  to confirm new setting.
9. Repeat steps 1-8 for each requested menu.








Showing/hiding menus in operator menu


1. Use forward key  to reach requested menu.
2. Press lock/unlock key  to unlock setting.
3. Use select key  to move cursor to $\sqrt{\quad} / \div$ symbol.
4. Press change key  to select visible ($\sqrt{\quad}$) or hidden (\div).
5. Press lock/unlock key  to confirm new setting.

6.6 Changing language

It is possible to change language in transmitter. Default language is English, but it can be changed to various other languages.

Change language as follows:

1. Press top up key  for 2 sec.
2. Enter password.
3. Use forward key  or backward key  to reach language menu.
4. Press lock/unlock key  to unlock language.
5. Use change key  to select desired language.
6. Press lock/unlock key  to confirm new language.
7. Press top up key  two times to exit setup mode.



Functions

7.1 Introduction

This chapter describes the various menus of the transmitter in details. The menu diagrams are shown in appendix Menu diagrams (Page 75).

7.2 Output settings

Three outputs are available:

- Current output (range and time constant); terminals 31 and 32.
- Digital output (pulse, frequency, error, limit, or batch settings); terminals 56, 57, and 58.
- Relay output (error, limit, and batch settings); terminals 44, 45, and 46.

Current output

In the current output menu it is possible to select current output direction, range and time constant, see also Current output menu diagram (Page 79).

If current output "4-20 mA + Alarm" is selected, then alarm level and alarm differentiation may also be defined.

"Alarm level" defines if an alarm should be above 21 mA "High" or below 3.6 mA "Low".

"Alarm diff." defines whether or not the alarm should vary according to selected error level. Error level "Fatal". "Permanent" or "Warning" is selected in "Basic settings".

If Alarm differentiation is set to "Yes", depending on the Alarm level setting, the current output will show:

| Alarm level | Output / Error level | | |
|-------------|----------------------|-----------|---------|
| | Fatal | Permanent | Warning |
| Low | 1.3 mA | 2 mA | 3 mA |
| High | 23 mA | 22 mA | 21.5 mA |

If Alarm differentiation is set to "No", depending on the Alarm level setting, the current output will show:

| Alarm level | Output |
|-------------|---------|
| Low | 3.5 mA |
| High | 22.6 mA |

For setting of error level, see Error level menu diagram (Page 79).

If current output is not used, it must be set to "Off".

Digital output

Digital output can be used to configure various settings:

- Pulse (volume/pulse, pulse output, pulse width, pulse polarity, and time constant), see Pulse menu diagram (Page 79).
- Frequency (frequency output, max frequency, and time constant), see Frequency menu diagram (Page 79).
- Error settings (level and number), see Error level menu diagram (Page 79) and Error number menu diagram (Page 80).
- Limit settings (number of setpoints, setpoint settings, and hysteresis), see Direction/limit menu diagram (Page 80).
- Batch settings (quantity, time and counter settings, and time constant), see Batch menu diagram (Page 81).

Note

When relay is set to batch function, pulse/frequency is not available on digital output.

Relay outputs

Relay output can be used to configure various settings:

- Error settings (level and number), see Error level menu diagram (Page 79) and Error number menu diagram (Page 80).
- Limit settings (number of setpoints, setpoint settings, and hysteresis), see Direction/limit menu diagram (Page 80).
- Batch settings (quantity, time and counter settings, and time constant), see Batch menu diagram (Page 81).

See also

Current output (Page 78)

7.3 External input

By applying 11 ... 30 V DC to terminals 77 and 78, it is possible to perform:

- Batch control (start, stop, hold/continue)
- Reset totalizer
- Force/freeze output
- $Q_{\max} 2$ (night)

See external input menu diagram (Page 82).

7.4 Sensor characteristics

The sensor characteristics menu shows:

- If a SENSORPROM® is installed or not
- Suppress error P 40 (SENSORPROM® not installed)
- Sensor size
- Calibration factor
- Correction factor
- Excitation

See Sensor characteristics (Page 83).







Note

If a SENSORPROM is not installed, check the sensor characteristics to see if they match the product label and the previous customer settings.

7.5 Reset mode

The reset mode is used for resetting/presetting totalizers or for restoring the factory settings.

Resetting

1. Press top up key  for 2 sec.
2. Enter password.
3. Use forward key  or backward key  to reach reset mode menu.
4. Press lock/unlock key  to enter reset menu.
5. Press forward key  to reach totalizer to be reset or default setting menu.
6. Press lock/unlock key  to start resetting.

If restoring of factory settings (Page 89) is required:

1. Press lock/unlock key  again to confirm destruction of customized settings.

See also reset menu diagram (Page 84).


7.6 Service mode

All outputs of the transmitter can be forced-controlled in the service mode menu, see Service mode (Page 85).

It is possible to check whether the outputs are functioning.

Error pending and status log lists are also accessible from this menu and the operating time (in days) can be read.

7.6 Service mode

The forced control is stopped and all previous settings are reinitialized the moment the service mode is left by pressing top up key .

Alarm, error, and system messages

8.1 Diagnostics

Error system

Transmitter system is equipped with an error and status log system with 4 groups of information.

(I) Information - system will continue to measure as normal, relay and current outputs will not be affected.

(W) Warning - system will continue to measure, but an event that may cause a system malfunction and require operator attention has occurred. The cause of the error may disappear on its own.

(P) Permanent error - may cause malfunction in the application and operator attention is required.

(F) Fatal error - is essential for the operation of the flowmeter. Immediate operator attention is required.

Two menus are available in service and operator menus for registration of information and errors.

- Error pending
- Status log

Note

Registration of errors in different modes

- In setup mode (local dialog) errors are entered only to Error pending list and not to Error log list, and not registered on physical outputs (current or relay).
- In service mode errors are entered to both Error pending and Error log lists, but not registered on physical outputs (current or relay).

Note

Power-off

Both error pending and status logs are reset at power-off.

Error pending

The first 9 pending errors are stored in the error pending list. When the error is corrected, it is removed from the error pending list.

The acceptance level for "error pending" can be individually configured to a particular application.

The acceptance level is set in the basic settings menu (Page 44).


8.1 Diagnostics

Acceptance levels

The following three acceptance levels are selectable.

- Fatal error: Only fatal errors are registered as errors
- Permanent error: Permanent and fatal errors are registered as errors
- Warning (Default value): Warnings, permanent and fatal errors are registered as errors

Error information is displayed in title and subtitle lines, see display layout (Page 41). Title line will show time in days, hours and minutes since occurrence of error. Subtitle line will flash between an error text and a remedy text. Error text will indicate type of error (I, W, P or F), error number, and error text. Remedy text will inform operator of action to take to remove error.



Status log

The latest 9 errors are stored in the status log. Errors are stored in the status log for 180 days, even if they are corrected.

Alarm field

The alarm field on the display will always flash when an error is pending.

Error output

The digital and relay output can be activated individually error by error (error level). The relay output is default selected to error level. An output can also be selected to activate on a single error number.

The alarm field, error output and error pending always operate together.

Operator menu

Error pending and status log are as default enabled (✓) in the operator menu.

8.2 List of error numbers

| Error No. | Error text Remedy text | Comment | Output status | Input status |
|-----------|--|--|----------------------|--------------|
| 1 | <i>I1 - Power on</i> OK | Device powered on | Active | Active |
| 2 | <i>I2 - Add-on module</i> Applied | A new module has been applied to the system | Active | Active |
| 3 | <i>I3 - Add-on module</i> Install | An add-on module is defect or has been removed. This can be an internal add-on module | Active | Active |
| 4 | <i>I4 - Param. corrected</i> OK | A less vital parameter in the transmitter has been replaced by its default value | Active | Active |
| 20 | <i>W20 - Totalizer 1</i> Reset manually | During initialisation the check of the saved totalizer value has failed. It is not possible to rely on the saved totalizer value anymore. The totalizer value must be reset manually in order to rely on future readings | Active | Active |
| 20 | <i>W20 - Totalizer 2</i> Reset manually | During initialisation the check of the saved totalizer value has failed. It is not possible to rely on the saved totalizer value anymore. The totalizer value must be reset manually in order to rely on future readings | Active | Active |
| 21 | <i>W21 - Pulse overflow</i> Adj. pulse settings | Actual flow is too big compared with pulse width and volume/pulse | Reduced pulse width | Active |
| 22 | <i>W22 - Batch timeout</i> Check installation | Duration of batching has exceeded a predefined maximum time | Batch output on zero | Active |
| 23 | <i>W23 - Batch overrun</i> Check installation | Batch volume has exceeded a predefined maximum overrun volume | Batch output on zero | Active |
| 24 | <i>W24 - Batch neg. flow</i> Check flow direction | Negative flow direction during batch | Active | Active |
| 30 | <i>W30 - Overflow</i> Adj. Q_{\max} | Flow is above Q_{\max} settings | Max. 120 % | Active |
| 31 | <i>W31 - Empty pipe</i> | Pipe is empty | Zero | Active |
| 40 | <i>P40 - SENSORPROM®</i> Insert/change | SENSORPROM® unit not installed | Active | Active |
| 41 | <i>P41 - Parameter range</i> Switch off and on | A parameter is out of range. The parameter could not be replaced by its default value. The error will disappear at the next power-on | Active | Active |

8.2 List of error numbers

| Error No. | Error text Remedy text | Comment | Output status | Input status |
|------------------|--|---|----------------------|---------------------|
| 42 | <i>P42 - Current output</i> Check cables | Current loop is disconnected or the loop resistance is too big | Active | Active |
| 43 | <i>P43 - Internal error</i> Switch off and on | Too many errors occurred at the same time. Some errors are not detected correctly | Active | Active |
| 44 | <i>P44 - CT SENSORPROM®</i> Replace | SENSORPROM® unit has been used as CT version | Active | Active |
| 49 | <i>P49 - Protection violation</i> Switch off and on | Internal protection of the device has been violated. | Active | |
| 60 | <i>F60 - CAN comm. error</i> Transmitter/AOM | CAN bus communication error. An add-on module, the display module or the transmitter is defective | Zero | Inactive |
| 61 | <i>F61 - SENSORPROM® error</i> Replace | It is not possible to rely on the data in SENSORPROM® unit anymore | Active | Active |
| 62 | <i>F62 - SENSORPROM® ID</i> Replace | The SENSORPROM® unit ID does not comply with the product ID. The SENSORPROM® unit is from another type of product SITRANS F C, SITRANS F US etc. | Zero | Inactive |
| 63 | <i>F63 - SENSORPROM®</i> Replace | It is not possible to read from the SENSORPROM® unit anymore | Active | Active |
| 70 | <i>F70 - Coil current</i> Check cables | Coil excitation has failed | Active | Active |
| 71 | <i>F71 - Internal error</i> Replace transmitter | Internal conversion error in ASIC | Active | Active |

Service and maintenance

Under ideal conditions the flowmeter will operate continuously with no manual adjustment or intervention required.

9.1 Maintenance

The device is maintenance-free. However, a periodic inspection according to pertinent directives and regulations must be carried out.

An inspection can include check of:

- Ambient conditions
- Seal integrity of the process connections, cable entries, and cover screws
- Reliability of power supply, lightning protection, and grounds

| |
|--|
| NOTICE |
| Repair and service must be carried out by Siemens authorized personnel only. |

Note

Siemens defines flow sensors as non-repairable products.

9.2 Certificates

You can find certificates on the Internet at Certificates (<https://www.siemens.com/processinstrumentation/certificates>) or on an included DVD.

9.3 Technical support

If you have any technical questions about the device described in these Operating Instructions and do not find the right answers, you can contact Customer Support:

- Via the Internet using the **Support Request**:
Support request (<http://www.siemens.com/automation/support-request>)
- Via Phone:
 - Europe: +49 (0)911 895 7222
 - America: +1 423 262 5710
 - Asia-Pacific: +86 10 6475 7575

Further information about our technical support is available on the Internet at Technical support (<http://support.automation.siemens.com/WW/view/en/16604318>)

Service & Support on the Internet

In addition to our documentation, we offer a comprehensive knowledge base online on the Internet at:

Service and support (<http://www.siemens.com/automation/service&support>)

There you will find:

- The latest product information, FAQs, downloads, tips and tricks.
- Our newsletter, providing you with the latest information about your products.
- Our bulletin board, where users and specialists share their knowledge worldwide.
- You can find your local contact partner for Industry Automation and Drives Technologies in our partner database.
- Information about field service, repairs, spare parts and lots more under **Services**.

Additional Support

If you have additional questions about the device, please contact your local Siemens representative and offices at:

Local contact person (http://www.automation.siemens.com/aspa_app/contactmenu.aspx?ci=yes®id=DEF&lang=en)

9.4 Return procedures

Enclose the delivery note, the cover note for return delivery and the declaration of decontamination form on the outside of the package in a well-fastened clear document pouch.

Required forms

- **Delivery Note**
- **Cover Note for Return Delivery** with the following information
Cover note (http://cache.automation.siemens.com/dnl/zY/zY00Tg1AAAA_16604370_TxtObj/Begleitschein_RW_AD.pdf)
 - product (ordering number)
 - number of devices or spare parts returned
 - reason for the return
- **Declaration of Decontamination**
Declaration of Decontamination (http://pia.khe.siemens.com/efiles/feldg/files/Service/declaration_of_decontamination_en.pdf)
With this declaration you certify that the returned products/spare parts have been carefully cleaned and are free from any residues.
If the device has been operated together with toxic, caustic, flammable or water-damaging products, clean the device before return by rinsing or neutralizing. Ensure that all cavities are free from dangerous substances. Then, double-check the device to ensure the cleaning is completed.
We shall not service a device or spare part unless the declaration of decontamination confirms proper decontamination of the device or spare part. Shipments without a declaration of decontamination shall be cleaned professionally at your expense before further proceeding.

You can find the forms on the Internet and on the CD delivered with the device.

Troubleshooting/FAQs

10.1 Troubleshooting guide

| Symptom | Output signals | Error code | Cause | Remedy |
|-------------------------------------|------------------------------|--|---|---|
| Empty display | Minimum | | 1. No power supply | Power supply Check MAG 5000/6000/6000 I for bended pins on the connector |
| | | | 2. MAG 5000/6000/6000 I defective | Replace MAG 5000/6000/6000 I |
| No flow signal | Minimum | | 1. Current output disabled | Turn on current output |
| | | | 2. Digital output disabled | Turn on digital output |
| | | | 3. Reverse flow direction | Change direction |
| | Undefined | F70 | Incorrect or no coil current | Check cables/connections |
| | | W31 | Measuring pipe empty | Ensure that the measuring pipe is full |
| | | F60 | Internal error | Replace MAG 5000/6000/6000 I |
| | | P42 | 1. No load on current output | Check cables/connections |
| 2. MAG 5000/6000/6000 I defective | Replace MAG 5000/6000/6000 I | | | |
| P41 | Initializing error | Switch off MAG 5000/6000/6000 I, wait 5 sec. and switch on again | | |
| Indicates flow with no flow in pipe | Undefined | | Measuring pipe empty | Select empty pipe cut-off |
| | | | Empty pipe cut-off is OFF | Ensure that the measuring pipe is full |
| | | | Electrode connection missing/ electrode cable is insufficiently screened | Ensure that electrode cable is connected and sufficiently screened |
| Unstable flow signal | Unstable | | 1. Pulsating flow | Increase time constant |
| | | | 2. Conductivity of medium too low | Use special electrode cable |
| | | | 3. Electrical noise potential between medium and sensor | Ensure sufficient potential equalization |
| | | | 4. Air bubbles in medium | Ensure medium does not contain air bubbles |
| | | | 5. High concentration of particles or fibres | Increase time constant |

10.2 Transmitter check list

| Symptom | Output signals | Error code | Cause | Remedy |
|---|---------------------|-----------------------|----------------------------------|---|
| Measuring error | Undefined | | Incorrect installation | Check installation |
| | | P40 | No SENSORPROM® unit | Install SENSORPROM® unit |
| | | P44 | CT SENSORPROM® unit | Replace SENSORPROM® unit or re-set SENSORPROM® unit with MAG CT transmitter |
| | | P49 | Protection violation | Switch off MAG 5000/6000/6000I, wait 5 sec. and switch on again. |
| | | F61 | Defective SENSORPROM® unit | Replace SENSORPROM® unit |
| | | F62 | Wrong type of SENSOR-PROM® unit | Replace SENSORPROM® unit |
| | | F63 | Defective SENSORPROM® unit | Replace SENSORPROM® unit |
| | | F71 | Loss of internal data | Replace MAG 5000/6000/6000 I |
| | Maximum | W30 | Flow exceeds 100% of Q_{max} . | Check Q_{max} (Basic Settings) |
| | | W21 | Pulse overflow | |
| Volume/pulse too small | Change volume/pulse | | | |
| | | Pulse width too large | Change pulse width | |
| Measuring approx. 50% | | | Missing one electrode connection | Check cables |
| Loss of totalizer data | OK | W20 | Initializing error | Reset totalizer manually |
| ##### Signs in display | OK | | Totalizer roll over | Reset totalizer or increase totalizer unit |
| Empty pipe error message when Empty pipe set to off | OK | W31 | Empty pipe error | Switch off MAG 5000/6000/6000I, wait 5 sec. and switch on again |

10.2 Transmitter check list

If unstable/wrong measurements occur, it is often due to insufficient/wrong earthing or potential equalization. If earthing connection is OK, check transmitter as described below, and sensor as described in sensor check lists (see the respective operating instructions).

As all settings are stored in and downloaded from the SENSORPROM®, replacement is easily done and no extra settings need to be made.

Check transmitter

Check transmitter according to the following check table:

| Power on transmitter | | |
|----------------------|---------------------------------|-------------------------|
| 0 | Display light on? | Yes ⇒ 1 |
| | | No ⇒ 2 |
| 1 | Flashing error triangles? | Yes ⇒ Check error table |
| | | No ⇒ 1.2 |
| 1.2 | Output and display readings OK? | Yes ⇒ 1.2.1 |
| | | No ⇒ 1.2.2 |

| Power on transmitter | | |
|-----------------------------|--------------------------|---|
| 1.2.1 | Transmitter OK | Check application Check installation/sensor/earthing connection etc. |
| 1.2.2 | Check cables/connections | OK ⇒ 1.2.1 |
| | | Not OK ⇒ correct fault |
| 2 | Check cables/connections | OK ⇒ 2.1 |
| | | Not OK ⇒ Correct fault |
| 2.1 | Output readings OK? | Yes ⇒ 2.1.1 |
| | | No ⇒ 2.1.2. |
| 2.1.1 | Display defective | Replace display |
| 2.1.2 | Transmitter defective | Replace transmitter |

Note

Sensor check list

Check lists for sensors are included in the respective sensor operating instructions.

Technical data

11.1 Technical specifications

| Technical specifications for MAG 6000 I standard and Ex version | | |
|---|--|--|
| Mode of operation and design | Measuring principle | Electromagnetic with pulsed constant field |
| | Empty pipe | Detection of empty pipe (special cable required in remote mounted installation) |
| | Excitation frequency | Depends on sensor size |
| | Electrode input impedance | $> 1 \times 10^{14} \Omega$ |
| Input | Digital input | 11 to 30 V DC, $R_i = 4.4 \text{ k}\Omega$ |
| | Activation time | 50 ms |
| | Current | $I_{11 \text{ V DC}} = 2.5 \text{ mA}$, $I_{30 \text{ V DC}} = 7 \text{ mA}$ |
| Output | Current output | |
| | Signal range | 0 to 20 mA (active/passive) |
| | Active current output | $R_{\text{max}} 500 \Omega @ V_{\text{max}} 30 \text{ V DC}$ |
| | Passive current output | $R_{\text{min}} 0 \Omega @ V_{\text{min}} 12 \text{ V DC}$ $R_{\text{max}} 500 \Omega @ V_{\text{max}} 30 \text{ V DC}$ |
| | Time constant | 0.1 to 30 s, adjustable |
| | Digital output | |
| | Frequency | 0 to 10 kHz, 50% duty cycle (uni/bidirectional) |
| | Time constant | 0.1 to 30 s, adjustable |
| | Pulse (passive) | 3 to 30 V DC, max. 110 mA (Ex version: max. 30 mA), $200 \Omega \leq R_i \leq 10 \text{ k}\Omega$ (powered from connected equipment) |
| | Time constant | 0.1 to 30 s, adjustable |
| | Relay output | |
| | Time constant | Changeover relay, same as current output |
| | Load | 30 VAC/2 A, 24 VDC/1 A |
| | Low flow cut off | 0 ... 9.9% of maximum flow |
| Galvanic isolation | All inputs and outputs are galvanically isolated PELV circuits with 60 VDC isolation from each other and ground. Exceptions are sensor connections that are connected to ground. | |
| Max. measuring error (incl. sensor and zero point) | MAG 6000 I/MAG 6000 I Ex de | $\pm 0.2\% \pm 1 \text{ mm/s}^{-1}$ |

Technical specifications for MAG 6000 I standard and Ex version

| Rated operation conditions | Ambient temperature | |
|-----------------------------------|--|--|
| | Operation | Standard version -25 to +60 °C (-13 to +140 °F) Ex version: -25 to +60 °C (-13 to +140 °F) |
| | Storage | -40 to +70 °C (-40 to +158 °F) |
| | Mechanical load | 18...1000 Hz random in x, y z, directions for 2 hours according to EN 60068-2-36 Transmitter: 1.14 grms |
| | Protection degree | IP67/NEMA 4X to IEC 60529 and DIN 40050 (1 mH ₂ O 30 min.) |
| | EMC performance | EN 61326 |
| Display and keypad | Totalizer | Two eight-digit counters for forward, net or reverse flow |
| | Display | Background illumination with alphanumeric text, 3 x 20 characters to indicate flow rate, totalized values, settings and faults; Reverse flow indicated by negative sign |
| | Keypad | Capacitive touch keypad with LED light for feedback indication |
| | Time constant | Time constant as current output time constant |
| Design | Enclosure material | Die cast aluminum with corrosion-resistant Basic Polyester power coating (min 60 μM) |
| | Wall mounting bracket | Bracket enclosed for remote mounting |
| | Dimensions | See dimensional drawings |
| | Weight | See dimensional drawings |
| Power supply | Standard version: | 100 to 230 VAC, 47 to 63 Hz 20 to 27 VDC |
| | Ex version: | 100 to 230 VAC, 47 to 63 Hz 20 to 27 VDC |
| Power consumption | 230 V AC: 21.5 VA 24 V DC: 12 W, I _N = 380 mA, I _{ST} = 1.5 A (10 ms) | |
| Certificates and approvals | Standard version | CE C-tick FM Class I, Div 2 FM Class I, Zone 2 CSA Class I, Div 2 CSA Class I, Zone 2 |
| | Ex version | Ex d e [ia] ia IIC T6 Gb Ex tD A21 IP67 T85°C Ta -25°C to +60°C FM Class I, II, III, Div 1 ³⁾ FM Class I, Zone 1/21 CSA Class I, Zone 1/21 |

Technical specifications for MAG 6000 I standard and Ex version

| | | |
|--|------------------|--|
| Cable entries (remote installation) | Standard version | 2 x M25 (for supply/output) and 2 x M16 (for sensor connection) or 2 x ½" NPT (for supply/output) and 2 x M16 (for sensor connection) |
| | Ex version | 2 x M20 (for supply/output) and 2 x M16 (for sensor connection) 2 x ½" NPT (for supply/output) and 2 x M16 (for sensor connection) |
| Communication | Standard version | HART, MODBUS RTU/RS485, Foundation Fieldbus H1, DeviceNet, and PROFIBUS PA/ DP add-on modules |
| | Ex version | HART, PROFIBUS PA and Foundation Field- bus H1 available factory-mounted |

¹⁾ Depending on sensor

²⁾ Only with MAG 3100 / 3100 P sensors sizes DN 15 ... DN 300 (½" ... 12") compact

11.2 Dimensions and weight

Transmitter IP67/NEMA 4X compact die cast aluminum




Figure 11-1 Transmitter dimensions shown in mm (inch)

Weight: MAG 6000 I/MAG 6000 I Ex de: 6 kg (13.5 lbs)

11.3 Accuracy

For accuracy reference conditions, see below.




Figure 11-2 MAG 6000 I / MAG 6000 I Ex de with MAG 1100 (not PFA), MAG 1100 HT, MAG 1100 F (not PFA), MAG 5100 W, MAG 3100 P, MAG 3100 and MAG 3100 HT

Reference conditions

(ISO 9104 and DIN/EN 29104)

A calibration certificate is shipped with every sensor and calibration data are stored in SENSORPROM® memory unit.

| | |
|--|---|
| Medium temperature | 20 °C ± 10 K (68°F ± 18 °F) |
| Ambient temperature | 25 °C ± 10 K (68°F ± 18 °F) |
| Supply voltage | $U_n \pm 1\%$ |
| Warming-up time | 30 minutes |
| Incorporation in conductive pipe section | |
| Inlet section | 10 x DN (DN ≤ 1200/48") 5 x DN (DN > 1200/48") |
| Outlet section | 5 x DN (DN ≤ 1200/48") 3 x DN (DN > 1200/48") |
| Flow conditions | Developed flow profile |

Reference conditions for sensor calibration


| | |
|--------------------------------|---|
| Current output | As pulse output ± (0.1% of actual flow + 0.05% FSO) |
| Effect of ambient temperature | < ± 0.003% / °C act. |
| Display/frequency/pulse output | |
| Current output | < ± 0.005% / °C act. |

| | |
|--------------------------|---|
| Effect of supply voltage | < 0.005% of measuring value on 1% change |
| Repeatability | ± 0.1% of actual flow for $V \geq 0.5$ m/s (1.5 ft/s) and conductivity $\geq 10 \mu\text{S/cm}$ |


Additions in the event of deviations from reference conditions

11.4 Output characteristics


Current output



Frequency output



Pulse output



Relay output

| Bidirectional mode | | Unidirectional mode | |
|--------------------|--|---------------------|--|
| Power down | | Active | |

Error relay output


| Bidirectional mode | | Unidirectional mode | |
|--------------------|--|---------------------|--|
| No error | | Error | |

Limit switch (can be used as direction switch)


| 1 set point | | 2 set points | |
|-------------------------------|--|-------------------------------|--|
| | | | |
| Passive Digital output | | Passive Digital output | |
| | | | |
| | | | |

Batch on digital output

Unidirectional mode (forward flow only)



Totalizer lap



Batch on relay output

| Unidirectional mode (forward flow only) | | | |
|---|--|-------|--|
| Hold | | Batch | |

83G922.10 83G923.10

11.5 Cable data

Description

| | |
|--|--|
| Electrode or coil cable (standard) | |
| Electrode cable, double shielded (for empty pipe detection or low conductivity fluids) | |
| Cable kit with standard coil cable and electrode cable double shielded (also available as low noise cable for MAG 1100 sensor) | |

Technical data

| | | Standard cable (electrode/coil) | Double-shielded cable (electrode) |
|---------------------|---------------------------|------------------------------------|--------------------------------------|
| Basic data | No. of conductors | 3 | 3 |
| | Sqr. area | 1.5 mm ² | 0.25 mm ² |
| | Screen | Yes | Double |
| | Color code | Brown, blue, black | Brown, blue, black |
| | Outside color | Grey | Grey |
| | Ext. diameter | 7.8 mm | 8.1 mm |
| | Conductor | Flexible CU | Flexible CU |
| | Isolation material | PVC | PVC |
| Ambient temperature | Flexible installation | -5 to +70°C (23 to 158°F) | -5 to +70°C (23 to 158°F) |
| | Non-flexible installation | -30 to +70°C (-22 to 158°F) | -30 to +70°C (-22 to 158°F) |
| Cable parameter | Capacity | 161.50 pF/m | - |
| | Inductance | 0.583 μH/m | - |
| | L/R | 43.83 μH/Ω | - |

For more information on cable lengths, empty pipe detection, and conductivity, see Operating Instructions for relevant sensor.

11.6 Cable requirements

| | | Coil cable | Electrode cable |
|----------------------------|--|---------------------|---------------------|
| Basic data | No. of conductors | 2 | 3 |
| | Min. sqr. area | 0.5 mm ² | 0.2 mm ² |
| | Screen | Yes | Yes |
| | Max. capacitance | N/A | 350 pF/m |
| Max. cable loop resistance | Media temperature: | | |
| | < 100 °C | 40 Ω | N/A |
| | > 200 °C | 6 Ω | N/A |
| Cable glands on sensor | M20x1.5 gland - Cable ø 5 to 13 mm (0.20 to 0.51 inches) | | |
| | ½ NPT gland - cable ø 5 to 9 mm (0.20 to 0.35 inches) | | |

 **WARNING**

Cable glands




For Ex zone 1 installations only certified cable glands with protection type "e" can be used for the power supply and the coil cable. The cable glands must be approved for the actual temperature and cable dimension.

Spare parts/Accessories






12.1 Ordering of spare parts

Ensure that your ordering data is not outdated. The latest ordering data is always available on the Internet: Catalog process instrumentation (<http://www.siemens.com/processinstrumentation/catalogs>)

12.2 Accessories

| Description | Order number | |
|--|---------------|---|
| Safety clamp | 7ME5933-0AC06 |  |
| Wall/pipe mounting bracket BI 2,5 DIN59382 X6Cr17 | 7ME5933-0AC05 |  |
| Communication modules for MAG 6000 I / MAG 6000 I Ex de | |  |
| HART | FDK-085U0321 | |
| Modbus RTU/RS485 | FDK-085U0234 | |
| PROFIBUS PA Profile 3 | FDK-085U0236 | |
| PROFIBUS DP Profile 3 | FDK-085U0237 | |
| Devicenet | FDK-085U0229 | |
| FOUNDATION Fieldbus H1 | A5E02054250 | |

12.3 Spare parts

| Description | Order number | |
|--|---------------|---|
| Standard wall mounting bracket Steel EN10088-2-1.4404 | 7ME5933-0AC04 |  |
| Display unit | FDK-085U3122 |  |
| Electronics cover with Ex glass plate | A5E02593565 |  |
| Cover for connection board incl. gasket (for remote version) | 7ME5933-0AC02 |  |
| Cover for mains supply/communication including gasket | 7ME5933-0AC03 |  |


Menu diagrams

A.1 Transmitter menu overview

The menu diagrams shown on the following pages apply to MAG 5000/6000 as well as MAG 6000 I.

Menu diagrams


A.1 Transmitter menu overview



83G794.17.02

- 1) Not available in MAG 5000
- 2) Add-on module
- 3) Factory-set password: 1000
- 4) Not available when batch
- 5) Only available when batch


A.2 Basic settings



- 1) The unit "BBL42" in the volume unit list is placed on the space for the customer unit (former "?"). The unit is shown as "BBL42" with the fitting conversion factor of 0.158987 m³, if not overwritten with customer's own unit text setup using PDM or ordered by using the Z-option Y20 in the ordering system.
The customer unit in the time unit list is displayed as "?". Via PDM or Y20 option this could e.g. be chosen as year "y".

- 2) When batch is selected on digital output or relay, Totalizer 2 is not shown because it is controlled by the batch function.


A.3 Current output




83C797.11.02

- 1) If HART communication is installed, it is not possible to set the output for 0-20 mA (even though the option is visible in the display). This is due to the fact that HART does not work if the output falls below 2-3 mA.
- 2) 4-20 mA + Alarm is the default setting for MAG 6000 I. For all other variants, the default setting is 4-20 mA.
- 3) For MAG 6000 I only: The controlling of alarm levels does not recognize if the jumper is mounted for passive output. Do not combine differentiation and low alarm level together with passive output. The output will try to pull down the level to 1.3 mA at fatal errors which is not possible for passive output.


A.4 Digital output - pulse




A.5 Digital output - frequency




A.6 Error level




A.7 Error number



A.8 Direction/limit



A.9 Batch




1) Visible only on Digital output.

Note

If batch function is chosen on the relay output, the digital output will be turned off if it has been set up for pulse, frequency or batch.

If digital output is set up for pulse, frequency or batch, then the relay output will be turned off if it has been set up for batch.


A.10 External input



- 1) The value showing totalizer 1 on the display is frozen for as long as the digital output is activated. However, totalizer 1 continues counting, and when the digital input is released, the value on the display again follows totalizer 1.
- 2) MAG 6000 I cannot be equipped with cleaning unit. The cleaning option for relay output is however possible. When selecting function for MAG 6000 I relay output, the relay output has the same behavior as if cleaning unit was installed.


The relay output of the transmitter determines when the relay is on by applying voltage for approximately 60 seconds. The metering is resumed after another 60 seconds when the cycle is complete. (The display is locked during this time). The time cycle can be set at 1 to 240 hours. If the cycle is set at for example three hours, the transmitter will be active every three hours.

A.11 Sensor characteristics




- 1) Error status (level or number) on an output is updated only at the time the error status changes (occurs or disappears). If P40 is suppressed after it has been detected (at power up), the output does not change state. In this case the power must be switched off/on to suppress the P40 error on the output.
- 2) The frequency can be set to 44 Hz in the MAG 6000 SV transmitter only.

A.12 Reset mode




83C840.11 .10.02

A.13 Service mode



- 1) Signal suitability is a level from 0 to 9 of the electrode measured voltage. Level 0 is equal to the limit value that is set for empty pipe error detection, and level 9 is the best signal measured.
- 2) If digital output is set to pulse (standard).
- 3) If digital output is set to frequency.


A.14 Operator menu setup



83GT1591.02

- 1) When selecting Batch amount for upper line, the upper line is initially blank. The amount done may not appear until the batch is started.
- 2) 'Text' means that the text for the chosen measured value is shown. For example, if text is chosen in line 2 and flow velocity is chosen in line 3, the text "Flow velocity" is shown in line 2 and the measured flow velocity is shown in line 3.


A.15 Product identity



836838.1.11.1.02

A.16 Add-on communication module

Example: HART



Note

Burst mode is not available with HART communication

Factory settings

B.1 Transmitter factory settings

The factory settings shown on the following pages apply to MAG 5000/6000 as well as MAG 6000 I.

| Menu item | Parameter | Factory settings | Options | More info |
|-----------------------|---------------------------|------------------------------|--|-----------------------------------|
| Password | Password | 1000 | 1000 to 9999 | Changing password (Page 43) |
| Basic settings | Flow direction | Positive | Positive, negative | Changing basic settings (Page 44) |
| | Q _{max} | Sensor size dependent | Sensor size dependent | |
| | • <i>volume unit</i> | <i>Sensor size dependent</i> | <i>m³, ml, l, hl, Ml, ft³, in³, US G, US kG, BBL32, BBL42, UK G, UK MG, ? (customer unit)</i> | |
| | • <i>time unit</i> | <i>Sensor size dependent</i> | <i>Sec., min., hour, day, ? (customer unit)</i> | |
| | Totalizer 1 | Forward | Forward, reverse, net | |
| | • <i>Totalizer 1 unit</i> | <i>Sensor size dependent</i> | <i>m³, ml, l, hl, Ml, ft³, in³, US G, US kG, BBL32, BBL42, UK G, UK MG, ? (customer unit)</i> | |
| | Totalizer 2 | Reverse | Forward, reverse, net | |
| | • <i>Totalizer 2 unit</i> | <i>Sensor size dependent</i> | <i>m³, ml, l, hl, Ml, ft³, in³, US G, US kG, BBL32, BBL42, UK G, UK MG, ? (customer unit)</i> | |
| | Low flow cut-off | 1.5% | 0 to 9.9% | |
| | Empty pipe | Off | On, Off | |
| | Velocity unit | m/s | m, mm, cm, dm, ft, in per s, min, h, d, ? (customer unit) | |
| Error level | Warning | Fatal, permanent, warning | | |

Factory settings

B.1 Transmitter factory settings

| Menu item | Parameter | Factory settings | Options | More info |
|------------------------|------------------------|---|--|--------------------------------------|
| Output | Current output | Off for MAG5000/6000 | On/off, Unidirectional/bidirectional, 0 to 20 mA/4 to 20 mA/4 to 20 mA + Alarm | Output settings (Page 49) |
| | • Alarm level | Low | High/Low | |
| | • Alarm diff. | No | Yes/No | |
| | • Time constant | 5 s | 0.1 to 30 s | |
| | Digital output | Pulse | Error, direction/limit, batch, frequency, pulse, error number, off | Digital output - pulse (Page 79) |
| | Relay output | Error level | Error, direction/limit, cleaning, error number, off | Error level (Page 79) |
| | Direction/limit switch | Off | 1 setpoint, 2 setpoints | Direction/limit (Page 80) |
| | • Setpoints | 0% | -100 to +100% | |
| | • Hysteresis | 5% | 0.0 to 100% | |
| | Batch | Off | | Batch (Page 81) |
| | • Batch quantity | 0 | Sensor size dependent | |
| | • Batch compensation | 0 | -100 to +100 m ³ | |
| | • Batch counter | Down | Up, down | |
| | Frequency | Off | 500 Hz, 1 kHz, 5 kHz, 10 kHz | Digital output - frequency (Page 79) |
| | • Time constant | 5 s | 0.1 to 30 s | |
| | Pulse | On | | Digital output - pulse (Page 79) |
| • Pulse polarity | Positive | Positive, negative | | |
| • Pulse width | 66 ms | 64 μs, 130 μs, 260 μs, 510 μs, 1.0 ms, 2.0 ms, 4.1 ms, 8.2 ms, 16 ms, 33 ms, 66 ms, 130 ms, 260 ms, 520 ms, 1.0 s, 2.1 s, 4.2 s | | |
| • Volume/pulse | Sensor size dependent | Dimension-dependent | | |
| • Time constant | 0.1 s | 0.1 to 30 s | | |
| External input | External input | Off | Batch, reset totalizer, freeze output, forced output, off | External input (Page 82) |
| | • Batch | Start | Start, hold/continue, stop, Qmax 2 | |
| Sensor characteristics | Correction factor | 1 | 0.85 to 2.00 | Sensor characteristics (Page 83) |
| Language | Language | English | English, German, French, Danish, Swedish, Finnish, Spanish, Russian, Italian, Portuguese, Polish | Changing language (Page 48) |

| Menu item | Parameter | Factory settings | Options | More info |
|---------------|----------------------|------------------|---|--|
| Operator menu | Primary field | Flow rate | Flow rate, Totalizer 1, Totalizer 2 | Changing operator menu setup (Page 47) |
| | Title/subtitle lines | Flow rate | Flow rate, Flow velocity, Qmax, Totalizer 1, Totalizer 2, Totalizer 1 reset, Totalizer 2 reset, Batch start/paused/stop, Batch cycle counter, Batch cycle counter reset, Sensor size, Sensor type, Error pending, Status log, Tag No. | |

B.2 50 Hz Dimension dependent Qmax

Table B-1 MAG 1100, MAG 1100 F, MAG 3100, MAG 3100 P and MAG 5100 W with M20 cable glands

| DN | Q _{max} * | | | | | unit |
|------------|--------------------|--------------------------------|----------|--|----------|-------------------|
| | Factory setting | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | | |
| mm (inch) | | min. | max. | min. | max. | |
| 2 (1/12) | 30 | - | - | 3.903623 | 156.1448 | l/h |
| 3 (1/8) | 70 | - | - | 6.361726 | 254.469 | l/h |
| 6 (1/4) | 300 | - | - | 25.44691 | 1017.876 | l/h |
| 10 (3/8) | 900 | - | - | 70.68584 | 2827.433 | l/h |
| 15 (1/2) | 2000 | - | - | 159.0432 | 6361.725 | l/h |
| 25 (1) | 5000 | 441.7865 | 17671.45 | 441.7865 | 17671.45 | l/h |
| 40 (1 1/2) | 12 | 1.130974 | 45.23893 | 1.130974 | 45.23893 | m ³ /h |
| 50 (2) | 20 | 1.574527 | 62.98107 | 1.767146 | 70.68583 | m ³ /h |
| 65 (2 1/2) | 30 | 2.499681 | 99.98723 | 2.986477 | 119.459 | m ³ /h |
| 80 (3) | 50 | 4.003646 | 160.1458 | 4.523894 | 180.9557 | m ³ /h |
| 100(4) | 120 | 6.252163 | 250.0864 | 7.068584 | 282.7433 | m ³ /h |
| 125 (5) | 180 | 10.00647 | 400.2585 | 11.04467 | 441.7864 | m ³ /h |
| 150 (6) | 250 | 15.74527 | 629.8107 | 15.90432 | 636.1725 | m ³ /h |
| 200(8) | 400 | 24.93797 | 997.5184 | 28.27434 | 1130.973 | m ³ /h |
| 250(10) | 700 | 40.00377 | 1600.15 | 44.17865 | 1767.145 | m ³ /h |
| 300 (12) | 1000 | 62.50395 | 2500.157 | 63.61726 | 254469 | m ³ /h |
| 350 (14) | 1200 | 86.59015 | 3463.605 | 86.59015 | 3463.605 | m ³ /h |
| 400 (16) | 1800 | 113.0974 | 4523.893 | 113.0974 | 4523.893 | m ³ /h |
| 450 (18) | 2000 | 143.1389 | 5725.552 | 143.1389 | 5725.552 | m ³ /h |
| 500 (20) | 3000 | 176.7146 | 7068.583 | 176.7146 | 7068.583 | m ³ /h |
| 600 (24) | 4000 | 254.4691 | 10178.76 | 254.4691 | 10178.76 | m ³ /h |
| 700 (28) | 4500 | 346.3606 | 13854.42 | 346.3606 | 13854.42 | m ³ /h |
| 750 (30) | 5000 | 397.6079 | 15904.31 | 397.6079 | 15904.31 | m ³ /h |
| 800 (32) | 7000 | 452.3894 | 18095.57 | 452.3894 | 18095.57 | m ³ /h |
| 900 (36) | 9000 | 572.5553 | 22902.21 | 572.5553 | 22902.21 | m ³ /h |
| 1000 (40) | 12000 | 706.8584 | 28274.33 | 706.8584 | 28274.33 | m ³ /h |
| 1050 (42) | 12000 | 706.8584 | 28274.33 | 706.8584 | 28274.33 | m ³ /h |

B.3 60 Hz Dimension dependent Qmax

| DN | Q _{max} * | | | | | unit |
|------------|--------------------|--------------------------------|----------|--|----------|-------------------|
| | Factory setting | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | | |
| mm (inch) | | | min. | max. | min. | max. |
| 1100 (44) | 14000 | 855.986 | 34211.94 | 855.2986 | 3421194 | m ³ /h |
| 1200 (48) | 15000 | 1017.877 | 40715.04 | 1017.877 | 40715.04 | m ³ /h |
| 1400 (54) | 25000 | - | - | 1385.443 | 55417.69 | m ³ /h |
| 1500 (60) | 30000 | - | - | 1590.432 | 63617.25 | m ³ /h |
| 1600 (66) | 35000 | - | - | 1809.558 | 72382.29 | m ³ /h |
| 1800 (72) | 40000 | - | - | 2290.222 | 91608.84 | m ³ /h |
| 2000 (78) | 45000 | - | - | 2827.434 | 113097.3 | m ³ /h |
| 2200 (90) | 50000 | - | - | 3421,195 | 136847.7 | m ³ /h |
| 2400 (96) | 55000 | - | - | 4071.505 | 162860.1 | m ³ /h |
| 2600 (102) | 60000 | - | - | 4778.363 | 191134.4 | m ³ /h |
| 280 (114) | 65000 | - | - | 5541.77 | 221670.7 | m ³ /h |
| 3000 (120) | 70000 | - | - | 6361.726 | 254469 | m ³ /h |

* The min. and max. amount values show mathematical values and do not indicate measurement accuracy

B.3 60 Hz Dimension dependent Qmax

Table B-2 MAG 1100, MAG 1100 F, MAG 3100, MAG 3100 P and MAG 5100 W with ½" NPT cable glands

| DN | Q _{max} * | | | | | unit |
|------------|--------------------|--------------------------------|----------|--|-----------|--------|
| | Factory setting* | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | | |
| mm (inch) | | | min. | max. | min. | max. |
| 2 (1/12) | 0.14 | - | - | 0.01718714 | 0.6874852 | US GPM |
| 3 (1/8) | 0.31 | - | - | 0.02800984 | 1.120393 | US GPM |
| 6 (1/4) | 1.4 | - | - | 0.1120394 | 4.481573 | US GPM |
| 10 (3/8) | 4 | - | - | 0.3112204 | 12.44881 | US GPM |
| 15 (1/2) | 9 | - | - | 0.7002459 | 28.0 | US GPM |
| 25 (1) | 23 | 1.945128 | 77.80509 | 1.945128 | 77.80509 | US GPM |
| 40 (1 1/2) | 53 | 4.979526 | 199.181 | 4.979526 | 199.181 | US GPM |
| 50 (2) | 89 | 6.932434 | 277.2973 | 7.78051 | 311.2203 | US GPM |
| 65 (2 1/2) | 133 | 11.00577 | 440.2305 | 13.14907 | 525.9624 | US GPM |
| 80 (3) | 221 | 17.62753 | 705.1008 | 19.91811 | 796.7241 | US GPM |
| 100(4) | 529 | 27.52745 | 1101.097 | 31.12204 | 1244.881 | US GPM |
| 125 (5) | 793 | 44.05714 | 1762.285 | 48.62819 | 1945.127 | US GPM |
| 150 (6) | 1101 | 69.32434 | 2772.973 | 70.02459 | 2800.984 | US GPM |
| 200 (8) | 1762 | 109.7986 | 4391.941 | 124.48819 | 4979.525 | US GPM |

| DN | Q _{max} | | | | | |
|------------|------------------|--------------------------------|----------|--|----------|--------|
| | Factory setting* | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | | unit |
| mm (inch) | | min. | max. | min. | max. | |
| 250 (10) | 3083 | 176.1313 | 7045.251 | 194.5128 | 7780.507 | US GPM |
| 300 (12) | 4403 | 275.1967 | 11007.86 | 280.0984 | 11203.93 | US GPM |
| 350 (14) | 5284 | 381.245 | 15249.79 | 381.245 | 15249.79 | US GPM |
| 400 (16) | 7926 | 497.9526 | 19918.1 | 497.9526 | 19918.1 | US GPM |
| 450 (18) | 8806 | 630.2213 | 25208.84 | 630.2213 | 25208.84 | US GPM |
| 500 (20) | 13209 | 778.051 | 31122.03 | 778.051 | 31122.03 | US GPM |
| 600 (24) | 17612 | 1120.394 | 44815.73 | 1120.394 | 44815.73 | US GPM |
| 700 (28) | 19813 | 1524.98 | 60999.19 | 1524.98 | 60999.19 | US GPM |
| 750 (30) | 22015 | 1750.615 | 70024.58 | 1750.615 | 70024.58 | US GPM |
| 800 (32) | 3082 | 1991.811 | 79672.4 | 1991.811 | 79672.41 | US GPM |
| 900 (36) | 39626 | 2520.885 | 100835.3 | 2520.885 | 100835.3 | US GPM |
| 1000 (40) | 52835 | 3112.204 | 124488.1 | 3112.204 | 124488.1 | US GPM |
| 1050 (42) | 52835 | 3112.204 | 137248.1 | 3112.204 | 124488.1 | US GPM |
| 1100 (44) | 61641 | 3765.767 | 150630.6 | 3765.767 | 150630.6 | US GPM |
| 1200 (48) | 66044 | 4481.574 | 179262.9 | 4481.574 | 179262.9 | US GPM |
| 1400 (54) | 110072 | - | - | 6099.92 | 243996.7 | US GPM |
| 1500 (60) | 1320867 | - | - | 7002.459 | 280098.3 | US GPM |
| 1600 (66) | 154101 | - | - | 7967.242 | 318689.6 | US GPM |
| 1800 (72) | 176115 | - | - | 10083.54 | 403341.5 | US GPM |
| 2000 (78) | 198130 | - | - | 12448.82 | 497952.5 | US GPM |
| 2200 (90) | 220144 | - | - | 15063.07 | 602522.6 | US GPM |
| 2400 (96) | 242158 | - | - | 17926.3 | 717051.7 | US GPM |
| 2600 (102) | 264173 | - | - | 21038.5 | 841539.8 | US GPM |
| 2800 (114) | 286187 | - | - | 24399.68 | 975987 | US GPM |
| 3000 (120) | 308201 | - | - | 28009.84 | 1120393 | US GPM |

* Factory setting sets Qmax to a metric unit (see previous table). The values here are converted to rounded off US GPM.

B.4 50 Hz Dimension dependent volume/pulse and batch

Table B-3 MAG 1100, MAG 1100 F, MAG 3100, MAG 3100 P and MAG 5100 W with ½" NPT cable glands

| DN | Volume/pulse or batch quantity* | | | | Factory setting | | |
|------------|---------------------------------|-------------|--|-------------|-----------------------------|--------------------|----------------|
| | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | | Volume/pulse & batch amount | Pulse & batch unit | Totalizer unit |
| mm (inch) | min. | max. | min. | max. | | | |
| 2 (1/12) | - | - | 3.61466 µl | 94.75103 l | 0.1 | ml | ml |
| 3 (1/8) | - | - | 5.890487 µl | 154.4155 l | 0.1 | ml | ml |
| 6 (1/4) | - | - | 23.56195 µl | 617.6622 l | 1 | l | l |
| 10 (3/8) | - | - | 65.44985 µl | 1.715728 m³ | 1 | l | l |
| 15 (1/2) | - | - | 147.2622 µl | 3.860389 m³ | 1 | l | l |
| 25 (1) | 409.0616 µl | 10.7233 m³ | 409.0616 µl | 10.7233 m³ | 10 | l | l** |
| 40 (1 1/2) | 1.047198 ml | 27.45165 m³ | 1.047198 ml | 27.45165 m³ | 10 | l | l** |
| 50 (2) | 1.457896 ml | 38.21785 m³ | 1.636247 ml | 42.89321 m³ | 10 | l | l** |
| 65 (2 1/2) | 2.31452 ml | 60.67373 m³ | 2.765257 ml | 72.48952 m³ | 100 | l | l** |
| 80 (3) | 3.70708 ml | 97.17886 m³ | 4.188791 ml | 109.8066 m³ | 100 | l | l** |
| 100(4) | 5.789039 ml | 151.7561 m³ | 6.544985 ml | 171.5728 m³ | 100 | l | l** |
| 125 (5) | 9.265244 ml | 242.8828 m³ | 10.22654 ml | 268.0825 m³ | 100 | l | m³ |
| 150 (6) | 14.57896 ml | 382.1785 m³ | 14.72622 ml | 386.0389 m³ | 100 | l | m³ |
| 200 (8) | 23.09071 ml | 605.309 m³ | 26.17994 ml | 686.2913 m³ | 1 | m³ | m³ |
| 250 (10) | 37.04053 ml | 970.995 m³ | 40.90616 ml | 1072.33 m³ | 1 | m³ | m³ |
| 300 (12) | 57.87403 ml | 1517.132 m³ | 58.90487 ml | 1544.155 m³ | 1 | m³ | m³ |
| 350 (14) | 80.17607 ml | 2101.767 m³ | 80.17607 ml | 210.7671 m³ | 1 | m³ | m³ |
| 400 (16) | 104.7198 ml | 2745.165 m³ | 104.7198 ml | 2745.165 m³ | 1 | m³ | m³ |
| 450 (18) | 132.536 ml | 3474.35 m³ | 132.536 ml | 3474.35 m³ | 1 | m³ | m³ |
| 500 (20) | 163.6247 ml | 4289.321 m³ | 163.6247 ml | 4289.321 m³ | 10 | m³ | m³ |
| 600 (24) | 235.6195 ml | 6176.622 m³ | 235.6195 ml | 6176.622 m³ | 10 | m³ | m³ |
| 700 (28) | 320.7043 ml | 8407.069 m³ | 320.7143 ml | 8407.069 m³ | 10 | m³ | m³ |
| 750 (30) | 368.1554 ml | 9650.972 m³ | 368.1554 ml | 9650.972 m³ | 10 | m³ | m³ |
| 800 (32) | 418.8791 ml | 10980.66 m³ | 418.8791 ml | 10980.66 m³ | 10 | m³ | m³ |
| 900 (36) | 530.1438 ml | 13897.4 m³ | 530.1438 ml | 13897.4 m³ | 10 | m³ | m³ |
| 1000 (40) | 654.4985 ml | 17157.28 m³ | 654.4985 ml | 17157.28 m³ | 10 | m³ | m³ |
| 1050 (42) | 654.4985 ml | 17157.28 m³ | 654.4985 ml | 17157.28 m³ | 10 | m³ | m³ |
| 1100 (44) | 79.94321 ml | 20760.31 m³ | 791.9432 ml | 20760.31 m³ | 10 | m³ | m³ |
| 1200 (48) | 942.4778 ml | 24706.48 m³ | 942.4778 ml | 24706.48 m³ | 10 | m³ | m³ |
| 1400 (54) | - | - | 1.282817 l | 33628.27 m³ | 10 | m³ | m³ |
| 1500 (60) | - | - | 1.472622 l | 38603.89 m³ | 10 | m³ | m³ |
| 1600 (66) | - | - | 1.675517 l | 43922.64 m³ | 10 | m³ | m³ |
| 1800 (72) | - | - | 2.120576 l | 55589.6 m³ | 10 | m³ | m³ |
| 2000 (78) | - | - | 2.617994 l | 68629.13 m³ | 10 | m³ | m³ |
| 2200 (90) | - | - | 3.167773 l | 83041.25 m³ | 10 | m³ | m³ |

B.5 60 Hz Dimension dependent volume/pulse and batch

| DN | Volume/pulse or batch quantity* | | | | Factory setting | | |
|------------|---------------------------------|------|--|-------------------------|-----------------------------|--------------------|----------------|
| | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | | Volume/pulse & batch amount | Pulse & batch unit | Totalizer unit |
| mm (inch) | min. | max. | min. | max. | | | |
| 2400 (96) | - | - | 3.769912 l | 98825.9 m ³ | 10 | m ³ | m ³ |
| 2600 (102) | - | - | 4.4241 l | 115983. m ³ | 10 | m ³ | m ³ |
| 2800 (114) | - | - | 5.131268 l | 134513.1 m ³ | 10 | m ³ | m ³ |
| 3000 (120) | - | - | 5.890487 l | 154415.5 m ³ | 10 | m ³ | m ³ |

* The min. and max. amount values show mathematical values and do not indicate measurement accuracy.

** For CT devices the totalizer 1 unit is in m³

B.5 60 Hz Dimension dependent volume/pulse and batch

Table B-4 MAG 1100, MAG 1100 F, MAG 3100, MAG 3100 P and MAG 5100 W with ½" NPT cable glands

| DN | Volume/pulse or batch quantity | | | |
|------------|--------------------------------|-----------|--|-----------|
| | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | |
| mm (inch) | US G min. | US G max. | US G min. | US G max. |
| 2 (1/12) | - | - | 0.00000095484069 | 25.03057 |
| 3 (1/8) | - | - | 0.000001556102 | 40.79227 |
| 6 (1/4) | - | - | 0.000006224408 | 163.1691 |
| 10 (3/8) | - | - | 0.00001729003 | 453.2475 |
| 15 (1/2) | - | - | 0.00003890255 | 1019.806 |
| 25 (1) | 0.0001080627 | 2832.796 | 0.0001080627 | 2832.796 |
| 40 (1 1/2) | 0.0002766404 | 7251.96 | 0.0002766404 | 7251.96 |
| 50 (2) | 0.0003851353 | 10096.08 | 0.0004322506 | 11331.18 |
| 65 (2 1/2) | 0.0006114314 | 16028.3 | 0.0007305034 | 19149.7 |
| 80 (3) | 0.0009793068 | 25671.93 | 0.001106562 | 29007.84 |
| 100(4) | 0.001529303 | 40089.74 | 0.001729003 | 45324.75 |
| 125 (5) | 0.002447619 | 64162.85 | 0.002701566 | 70819.92 |
| 150 (6) | 0.003851353 | 100960.8 | 0.003890255 | 101980.6 |
| 200 (8) | 0.00609992 | 159905.7 | 0.006916009 | 181299 |
| 250 (10) | 0.009785071 | 256509.7 | 0.01080627 | 283279.6 |
| 300 (12) | 0.01528871 | 400784.1 | 0.01556102 | 407922.7 |
| 350 (14) | 0.02118028 | 555228.2 | 0.02118028 | 555228.2 |
| 400 (16) | 0.02766404 | 725196 | 0.02766404 | 725196 |
| 450 (18) | 0.0350123 | 917826.2 | 0.0350123 | 917826.2 |
| 500 (20) | 0.04322506 | 1133118 | 0.04322506 | 1133118 |

Factory settings

B.5 60 Hz Dimension dependent volume/pulse and batch

| DN | Volume/pulse or batch quantity | | | |
|------------|--------------------------------|-----------|---|-----------|
| | MAG 5100 W (Order no. 7ME6520) | | MAG 1100, MAG 1100 F, 5100 W (Order no. 7ME6580), MAG 3100, 3100 P | |
| mm (inch) | US G min. | US G max. | US G min. | US G max. |
| 600 (24) | 0.06224408 | 1631691 | 0.06224408 | 1631691 |
| 700 (28) | 0.0847211 | 2220912 | 0.0847211 | 2220912 |
| 750 (30) | 0.09725637 | 2549517 | 0.09725637 | 2549517 |
| 800 (32) | 0.1106562 | 2900784 | 0.1106562 | 2900784 |
| 900 (36) | 0.1400492 | 3671304 | 0.1400492 | 3671304 |
| 1000 (40) | 0.1729003 | 4532475 | 0.1729003 | 4532475 |
| 1050 (42) | 0.1729003 | 4532475 | 0.1729003 | 4532475 |
| 1100 (44) | 0.2092093 | 5484294 | 0.2092093 | 5484294 |
| 1200 (48) | 0.2489763 | 6526764 | 0.2489763 | 6526764 |
| 1400 (54) | - | - | 0.3388844 | 8883651 |
| 1500 (60) | - | - | 0.3890255 | 10198060 |
| 1600 (66) | - | - | 0.4426246 | 11603130 |
| 1800 (72) | - | - | 0.5601967 | 14685210 |
| 2000 (78) | - | - | 0.6916009 | 18129900 |
| 2200 (90) | | | 0.836837 | 21937170 |
| 2400 (96) | | | 0.995906 | 26107050 |
| 2600 (102) | | | 1.168806 | 30639530 |
| 2800 (114) | | | 1.355538 | 35534600 |
| 3000 (120) | | | 1.556102 | 40792270 |


Control drawing

C.1 Control drawing

A5E03828041A

FM Control drawing

MAG6000 I / MAG3100

| | | | | | |
|---|-------------|----------------|-----------------|---|-----------------------|
|  | | | | | |
| Prod. family: | Transmitter | | | | |
| Prod.gr.: | MAG6000 I | Fab. Group: | 4838 | FM Control Drawing MAG6000 I / MAG3100 | Paper size: A4 |
| | | Date: | 19-12-2013 | | Sheet 1 of 4 |
| DS | 07 | Author: | G.Joergensen | | |
| Init. Date | | Check | John Beck Nyrup | | |
| Editor | E.Breede | Department: | SFID | Part no.: | |
| | | SIEMENS | Document no.: | A5E03828041A | Type: ZUL |

SITRANS F M MAG6000 I and MAG3100 compact zone wiring


User I/O INTERFACE

| Current (31.32) | | Relay (44.45.46) | | Freq./pulse (56.57) | | Prof. (85, 90) (FISCO) | | Dig. Input (77.78) | |
|-----------------|-------|------------------|-------|---------------------|-------|------------------------|-------|--------------------|------|
| IB/IIC | | IB/IIC | | IB/IIC | | IB/IIC | | IB/IIC | |
| Ui | 30V | Ui | 30V | Ui | 28V | Ui | 17.5V | Ui | 30V |
| Ii | 100mA | Ii | 200mA | Ii | 100mA | Ii | 380mA | Ii | |
| Ci | 22nF | Ci | 7.5nF | Ci | 11nF | Ci | 0 | Ci | 0 |
| Li | 34µH | Li | 0 | Li | 34µH | Li | 0 | Li | 0 |
| Pi | 1W | Pi | 1.2W | Pi | 1.2W | Pi | 5.32W | Pi | 1.2W |

- No revision to drawing without prior FM Approval.
 - The Associated Apparatus must be FM Approved.
 - The FM Approved Associated Apparatus must be a linear output device.
 - Control equipment connected to Associated Apparatus must not use or generate more than 250 Vrms or Vdc.
 - Associated apparatus manufacturer's installation drawing must be followed when installing this equipment.
 - The Entity Concept allows interconnection of intrinsically safe apparatus with associated apparatus when the following is true:
 - V_{max} or $U_i \geq V_{oc}$, V_t or U_o ;
 - I_{max} or $I_i \geq I_{sc}$, I_t or I_o ;
 - P_{max} or $P_i \geq P_o$;
 - C_a or $C_o \geq C_i + C_{cable}$;
 - L_a or $L_o \geq L_i + L_{cable}$.
 - Resistance between Intrinsically Safe Ground and earth ground must be less than 1.0 Ohm.
 - Installation should be in accordance with ANSI/ISA RP12.06.01 "Installation of Intrinsically Safe Systems for Hazardous(Classified) Locations" and the National Electrical Code (ANSI/NFPA 70).
 - See operating Instructions for SITRANS FM order no. A5E31638071 to complete installation
- WARNING - The equipment shall not be opened when an explosive gas or dust atmosphere may be present.
- WARNING – Substitution of components may impair Intrinsic Safety.
- WARNING – To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing

Non hazardous Location

Hazardous location
 Sizes DN15 to DN2000:
 Class I, Zone 1, AEx de [ia] ia IIC T3 - T6
 Zone 21, AEx tD T85°C - 200°C Type 4X/IP67



Housing of Transmitter and Sensor must always be connected as illustrated


Control drawing

C.1 Control drawing

SITRANS F M MAG6000 I and MAG3100 remote Zone wiring

| User I/O INTERFACE | | | | | | | | | | Sensor interface | | | |
|--------------------|-------|------------------|-------|---------------------|-------|---|------|------------------------|--------|------------------|--------|--|--|
| Current (31,32) | | Relay (44,45,46) | | Freq./pulse (56,57) | | Prof. (85, 86) (FISCO) Dig. Input (77,78) | | Sensor (0,81,82,83,84) | | (85,86) Ex e | | | |
| IB/IIC | UI | IB/IIC | UI | IB/IIC | UI | IB/IIC | UI | Uo | Io | Ic | Um | | |
| 30V | 30V | 30V | 28V | 17.5V | 17.5V | 30V | 30V | 30V | 30V | 30V | 70V | | |
| 100mA | 100mA | 200mA | 100mA | 380mA | 380mA | 0 | 0 | 6.1mA | 6.1mA | 6.1mA | 6.1mA | | |
| 22nF | 22nF | 7.5nF | 11nF | 0 | 0 | 0 | 0 | 500nF | 500nF | 500nF | 500nF | | |
| 34μH | 34μH | 0 | 0 | 0 | 0 | 0 | 0 | 1H | 1H | 1H | 1H | | |
| 1W | 1W | 1.2W | 1.2W | 5.32W | 5.32W | 1.2W | 1.2W | 45.5mW | 45.5mW | 45.5mW | 45.5mW | | |

- No revision to drawing without prior FM Approval.
 - The Associated Apparatus must be FM Approved.
 - The FM Approved Associated Apparatus must be a linear output device.
 - Control equipment connected to Associated Apparatus must not use or generate more than 250 Vrms or Vdc.
 - Associated apparatus manufacturer's installation drawing must be followed when installing this equipment.
 - The Entity Concept allows interconnection of intrinsically safe apparatus with associated apparatus when the following is true:
 - V_{max} or $U_i \geq V_{oc}$, V_t or U_o ;
 - I_{max} or $I_i \geq I_{sc}$, I_t or I_o ;
 - P_{max} or $P_i \geq P_o$;
 - C_a or $C_o \geq C_i + C_{cable}$;
 - L_a or $L_o \geq L_i + L_{cable}$.
 - Resistance between Intrinsically Safe Ground and earth ground must be less than 1.0 Ohm.
 - Installation should be in accordance with ANSI/ISA RP12.06.01 "Installation of Intrinsically Safe Systems for Hazardous(Classified) Locations" and the National Electrical Code (ANSI/NFPA 70).
 - See operating Instructions for SITRANS FM order no. A5E31638071 to complete installation
- WARNING - The equipment shall not be opened when an explosive gas or dust atmosphere may be present.
- WARNING - Substitution of components may impair Intrinsic Safety.
- WARNING - To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing




Housing of Transmitter and Sensor must always be connected as illustrated

SITRANS F M MAG6000 I and MAG3100 compact Division wiring

1. No revision to drawing without prior FM Approval.
 2. Resistance between Intrinsically Safe Ground and earth ground must be less than 1.0 Ohm.
 3. Conduit seal must be installed within 18" of conduit entry and when transitioning between hazardous locations .
 4. Installation should be in accordance with ANSI/ISA RP12.06.01 "Installation of Intrinsically Safe Systems for Hazardous(Classified) Locations" and the National Electrical Code (ANSI/NFPA 70).
 5. See operating Instructions for SITRANS FM order no. A5E31638071 to complete installation
- WARNING - The equipment shall not be opened when an explosive gas or dust atmosphere may be present.
- WARNING – Substitution of components may impair Intrinsic Safety.
- WARNING – To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing

Non hazardous Location

Hazardous location
Sizes DN15 to DN300:
Class I, Div 1, Groups A, B, C, D
Class II, III Div 1, Groups E, F, G;
Type 4X/IP67



Housing of Transmitter and Sensor must always be connected as illustrated

Index

A

Add-on modules, (See Communication module)
 Electrical connection: Add-on modules, 38
Alarm differentiation, 49
Alarm level, 49

B

Batch function, 49

C

Cable specifications, 29
Certificates, 57
Communication modules, 19, 21
Compliance, 11
Connection
 Electrical, (See Electrical connection)
Contact person, 9
Current output, 49
Customer Support Hotline, 57

D

Decontamination, 58
Design, 20
Device
 Identification, 9
 Inspection, 8
Diagnostic functions, 53
Digital output, 50
Document History, 7

E

Electrical connection, 38
 Basic requirements, 34
 Cable specifications, 29
 In hazardous area, 37
 Safety, 29
Error handling, 53

H

Hazardous area
 Electrical connection, 37
 Special conditions, 16
Hotline, 57

I

Installation
 Pipe mounting, 28
 Safety instructions, 23
Installation examples, 37
Internet
 Contact person, 9, 58
 Flow documentation, 9
 Support, 58
Intrinsically safe data, 14
Introduction, 7
Items supplied, 7

L

Laws and directives, 11

M

Mains supply, 30
Maintenance, 57
Material compatibility, 12
Measurement principle, 21
Menu structure, 43, 49

N

Nameplate, 9

P

Plug & Play, 21
Pressure
 Safety instructions, 23

R

Relay outputs, 50
Repair, 57
Return procedures, 58

S

Safety, 11
 Instrument safety standards, 11
 Sensor installation, 23
Sensorprom, 21
Service, 57, 58
Settings, 49
Support, 58
System components, 19

T

Theory of operation, 21
Troubleshooting, 61

W

Wiring, (See Electrical connection)