

Pressure gauge model 2 NS 63 per ATEX directive



4375378.01 • 12/2019 EN/DE





Contents

- 1. General information
- 2. Safety
 - 2.1 Intended use
 - 2.2 Responsibility of the operator
 - 2.3 Personnel qualification
 - 2.4 Safety instructions for hazardous locations
 - 2.5 Labelling / Safety marks
 - 2.6 Special conditions for safe use (X conditions)
 - 2.7 Ignition hazard analysis
- 3. Specifications
- 4. Design and function
- 5. Transport, packaging and storage
- 6. Commissioning, operation
- 7. Faults
- 8. Maintenance and cleaning
- 9. Dismounting, return and disposal

Annex: EU Declaration of conformity

Declarations of conformity can be found online at www.wika.com.

1. General information

- The pressure gauge described in the operating instructions has been designed and manufactured using state-of-the-art technology.
- All components are subject to stringent quality and environmental criteria during production. Our management systems are certified to ISO 9001 and ISO 14001.
- These operating instructions contain important information on handling the instrument. Working safely requires that all safety instructions and work instructions are observed.
- Observe the relevant local accident prevention regulations and general safety regulations for the instrument's range of use.
- The operating instructions are part of the product and must be kept in the immediate vicinity of the instrument and readily accessible to skilled personnel at any time.
- Skilled personnel must have carefully read and understood the operating instructions prior to beginning any work.
- The manufacturer's liability is void in the case of any damage caused by using the product contrary to its intended use, non-compliance with these operating instructions, assignment of insufficiently qualified skilled personnel or unauthorised modifications to the instrument.
- The general terms and conditions contained in the sales documentation shall apply.
- Subject to technical modifications.
- Further information:
 - Internet address: www.wika.de

www.wika.com

Model	Model ID	Data sheet
232.50.063, 233.50.063, 262.50.063, 263.50.063	A	PM 02.02
232.30.063, 233.30.063, 262.30.063, 263.30.063	В	PM 02.04
PG23LT	D	PM 02.22
PG23CP	E	PM 02.24
232.53, 232.54, 233.53, 233.54	F	-

Explanation of symbols



WARNING!

indicates a potentially dangerous situation that can result in serious injury or death, if not avoided.



Information

... points out useful tips, recommendations and information for efficient and trouble-free operation.



.. indicates a potentially dangerous situation in the hazardous area that results in serious injury or death, if not avoided.

2. Safety



WADNING

Before installation, commissioning and operation, ensure that the appropriate pressure gauge has been selected in terms of measuring range, design and specific measuring conditions.

Check the compatibility with the medium of the materials subjected to pressure!

In order to guarantee the measurement accuracy and long-term stability specified, the corresponding load limits must be observed.



Non-observance can result in serious injury and/or damage to property.

Further important safety instructions can be found in the individual chapters of these operating instructions.

2.1 Intended use

These pressure gauges are used for measuring pressure in hazardous areas of industrial applications.

Classification per European pressure equipment directive

- Instrument type: Pressure accessory without safety function
- Media: Liquid or gaseous, group 1 (dangerous)
- Maximum permissible pressure PS, see chapter 2.5 "Labelling / safety marks"
- Volume: < 0.1 l</p>

The instrument must only be used with media which are not harmful to the wetted parts over the entire operating range of the instrument. Any change in the state of the matter or any decomposition of unstable media is not permitted.

Only use the instrument in applications that lie within its technical performance limits (e.g. max. ambient temperature, material compatibility, ...).

→ For performance limits see chapter 9 "Specifications".

Suitability for use in accordance with model ID

See chapter 1 for the assignment of model ID to model.

Application			Model ID					
	Α	В	D	Е	F			
Gaseous and liquid aggressive media that are not highly viscous or crystallising, also in aggressive environments	•	•	•	•	•			
Process industry: Chemical industry, petrochemical industry, oil and gas, power generation, water and wastewater technology, machine building and general plant construction				•	•			
High dynamic pressure loads and vibrations (only with optional case liquid filling)	•	•	•	•	•			
Increased safety requirements for personal protection 1)		•	•	•				
For outdoor use with ambient temperatures down to -70 °C			•					
Particularly suitable for use in wellhead control panels (WHCPs) and hydraulic power units (HPUs)				•				

¹⁾ Option or model 2xx.3

The instrument has been designed and built solely for the intended use described here, and may only be used accordingly.

The manufacturer shall not be liable for claims of any type based on operation contrary to the intended use.

2.2 Responsibility of the operator

The legibility of the marking must be observed during time in use but at least during inspection periods of three years. If any harm of the legibility is found please contact the manufacturer to renew the marking.

For the safety of the system, the operator is obliged to carry out an ignition source analysis. The responsibility for classification of zones lies with the plant operator and not the manufacturer/ supplier of the equipment.

These ignition sources must be taken into account for the instrument:

1. Hot surfaces

The surface of the instrument can heat up due to the temperature of the process medium. This depends on the installation situation and must be taken into account by the operator.

2. Mechanically generated sparks

Mechanically generated sparks are a potential ignition source. If the materials used exceed a total mass percentage of 7.5 % magnesium, titanium and zirconium, the operator must take appropriate protective measures.

3. Static electricity

- To avoid electrostatic charging, the instrument must be included in the equipotential bonding
 of the system. This can be done via the process connection or other suitable measures.
- The instrument can optionally contain components with a non-conductive surface coating or lining. In such cases, the operator must take appropriate measures to prevent electrostatic charging.
- Metal components of the instruments (e.g. TAG plates) must be included in the equipotential bonding of the system during installation and operation.

4. Adiabatic compression and shock waves

With gaseous media, the temperature may increase as a result of compression warming. In these cases it may be necessary to throttle the rate of change of pressure or reduce the permissible medium temperature.

5. Chemical reactions

The operator must ensure that chemical reactions between wetted parts, process medium and environment are excluded. The materials used can be found in the instrument marking.



On the wetted parts of the instrument, small residual amounts of the adjustment medium (e.g. compressed air, water, oil) can adhere from production. With increased requirements for technical cleanliness, suitability for the application must be checked by the operator before commissioning.



Liquid media with the property of changing the volume during solidification can damage the measuring system (e.g. water if it falls below the freezing point).

2.3 Personnel qualification



WARNING

Risk of injury should qualification be insufficient!

Improper handling can result in considerable injury and damage to property. The activities described in these operating instructions may only be carried out by

skilled personnel who have the qualifications described below.

Skilled personnel

Skilled personnel are understood to be personnel who, based on their technical training, knowledge of measurement and control technology and on their experience and knowledge of country-specific regulations, current standards and directives, are capable of carrying out the work described and independently recognising potential hazards.

Safety instructions for hazardous locations



WARNING!

Non-observance of these instructions and their contents may result in the loss of explosion protection.



WARNING!

It is imperative that the application conditions and safety requirements of the EU-type examination certificate are followed.

Pressure gauges must be grounded via the process connection.



For use in ambient temperatures below the freezing point of water, filled instruments are recommended. The case filling prevents the formation of and freezing of condensation in the case.

Permissible ambient temperature

Model 232/262/PG23CP: -40 ... +60 °C (unfilled) Model 233/263/PG23CP: -20 ... +60 °C (glycerine filling)

-40 ... +60 °C (silicone oil filling)

-70 ... +60 °C (silicone oil filling) Model PG23IT-

Attention! With gaseous media, the temperature may increase as a result of compression warming. In these cases it may be necessary to throttle the rate of change of pressure or reduce the permissible medium temperature.

Permissible medium temperature

< 100 °C (with case filling)

≤ 200 °C (unfilled)

The permissible medium temperature does not only depend on the instrument design, but also on the ignition temperature of the surrounding gases, vapours or dusts. Both aspects have to be taken into account.

Maximum surface temperature

The surface temperature of the instruments mainly depends on the medium temperature of the application. The instrument itself does not contain any heat sources. For determining the maximum surface temperature, besides the medium temperature also other influences such as the ambient temperature and, if applicable, the solar irradiation must be taken into account. For prevention, consider the maximum medium temperature as maximum surface temperature, if it is not possible to determine the real surface temperature even in the case of expected malfunctions. For prevention, consider the maximum medium temperature as maximum surface temperature, if it is not possible to determine the real surface temperature even in the case of expected malfunctions.

Potentially explosive gas atmosphere

Required temperature class (ignition tempera-	Maximum permissible surface temperature of the instrument (for the end application)					
ture of gas or vapour)	Models 232, 262, PG23CP (unfilled instruments)	Models 233, 263, PG23LT, PG23CP (filled instruments)				
T6 (T > 85 °C)	+65 °C	+65 °C				
T5 (T > 100 °C)	+80 °C	+80 °C				
T4 (T > 135 °C)	+105 °C	+100 °C				
T3 (T > 200 °C)	+160 °C	+100 °C				
T2 (T > 300 °C)	+200 °C	+100 °C				
T1 (T > 450 °C)	+200 °C	+100 °C				

Hazardous dust atmosphere

For dusts, the procedure specified in ISO/IEC 80079-20-2 for determining the ignition temperature has to be applied. The ignition temperature is determined separately for dust clouds and dust layers, respectively. For dust layers, the ignition temperature depends on the dust layer thickness per IEC/EN 60079-14.

	Maximum permissible surface temperature of the instrument (for the end application)
Dust cloud: T _{cloud}	< 2/3 T _{cloud}
Dust layer: T _{layer}	< T _{layer} - 75 K - (reduction depending on the layer thickness)

The permissible maximum medium temperature must not exceed the lowest determined value, even in case of a malfunction.

Explosive atmosphere consisting of hybrid mixtures

The instruments must not be used in areas in which an atmosphere consisting of explosive hybrid mixtures (dusts mixed with gases) can occur.

Handling of materials

Avoid exposing the instrument to any substances or environmental conditions that could negatively affect the instrument and the materials used. Avoid handling substances that are liable to spontaneous combustion. For a list of the materials used, see chapter 8 "Specifications". The materials of the wetted parts are stated on the dial.

Clean the measuring instrument with a moist cloth. Ensure that due to the cleaning no electrostatic charge will be generated.

Special hazards



WARNING!

For hazardous media such as oxygen, acetylene, flammable or toxic gases or liquids, and refrigeration plants, compressors, etc., in addition to all standard regulations, the appropriate existing codes or regulations must also be followed.

With pressure gauges which do not correspond to a safety version per EN 837 highly pressurised media might leak out through the possibly bursting window in case of a component failure.



For gaseous media and operating pressures > 25 bar a pressure gauge with safety version S3 is recommended per EN 837-2.



WARNING!

Residual media in dismounted pressure gauges can result in a risk to persons, the environment and equipment.

Take sufficient precautionary measures.

Ex marking

Ex mark	king per 2014/34/EU				Ex marking per ISO 80079-36/37					
Α	В	С	D	Е	1	2	3	4	5	6
CE	$\langle E_{X} \rangle$	II	2	G	Ex	h	IIC	T6 T1	Gb	Χ
~	(CX)	II	2	D	Ex	h	IIIC	T85°C T450°C	Db	Χ


		11 2	_	LX	11	IIIO	105 0 140	.0 0	Db	X	
ID	Marking	Designa	Mea	Meaning							
Α	CE	CE marking		Euro	European conformity						
В	⟨Ex⟩		narking for protection		Ex symbol						
С	II	Symbol of equipmen	part	Equipment intended for use in other places than underground parts of mines, and in those parts of surface installations of such mines, liable to be endangered by firedamp and/or combustible dust and an explosive atmosphere.							
D	2	Symbol of equipmen	the tcategory	High	n safety,	approve	d for zone 1 an	d 21			
E	G	Ex atmosp	ohere		areas in oresent		plosive gas, va	apour, mist o	r air mix	tures	
	D	Ex atmosphere For areas in which explosive atmospheres caused by of form.				ed by dı	ust can				
1	Ex	Ex markin	Ex marking		Standards ISO 80079-36 and ISO 80079-37 applied						
2	h	Ignition pr type	otection		Non-electrical equipment for use in explosive atmospheres An ignition protection type is not applied to the letter "h".						
3	IIC	Suitable a	tmosphere	Gas atmosphere group IIC							
	IIIC			Con	Combustible flyings, non-conductive dust and conductive of						
4	TX	Maximum temperatu		The	actual r	naximum	e temperature surface temper mainly on the	erature depe			
5	Gb Db	EPL equipment protection level			Potential ignition sources that are effective or may become effective during normal operation and expected malfunction.						
6	X	Specific c of use, se- instruction	e operating		oient ter se apply		with special ra	ange. Specif	ic condi	tions	

2.5 Labelling / Safety marks

Dial

Materials of wetted parts


Product label



Warning label for electrostatic charging (optional)

Additional label for liquid filling (option for model PG23CP)





- ① Model
- ② Volume specification per pressure equipment directive
- ③ Maximum permissible pressure PS
- Serial number
- S Year of manufacture
- Article number
- ⑦ Case filling



Before mounting and commissioning the instrument, ensure you read the operating instructions!



The instrument bearing this mark is a safety pressure gauge with a solid baffle wall in accordance with EN 837.

2.6 Special conditions for safe use (X conditions)

- 1. All accessories (e.g. valves or attachment components) must be assessed in combination with the delivered instruments by the end user.
- 2. The operator must recognise ignition hazards and take suitable protective measures. See chapter 2.2 "Responsibility of the operator".
- The legibility of the marking must be observed during time in use but at least during inspection periods of three years. See chapter 2.2 "Responsibility of the operator".
- 4. For instruments with marking pointer, ensure that there are no electrostatic charging mechanisms at the marking pointer. 5. Avoid any kind of external impact. External impacts can generate sparks through friction
- processes between different materials.

 6. The filling/refilling of instruments by non-authorised personnel leads to a loss of the explosion protection and can lead to damage to the instrument.

Ignition hazard analysis

ignition nazara analysis							
Relevant identified ignition hazards	Implemented protective measures						
Hot surfaces	 The actual surface temperature depends on the application, i.e. on the medium temperature Temperature range marking; T range marking Observation of legibility of marking Information given in operating instructions 						
Mechanically generated sparks and hot surfaces	 Low contact speed Limitation of vibration Selection of suitable materials Information given in operating instructions 						
Stray electric currents, ca- thodic corrosion protection	 Grounding via process connection required Information given in operating instructions 						
Static electricity	 No propagating brush discharge All conductive parts bonded Limitation of projected area of non-conductive parts Limitation of layer thickness of non-conductive parts Grounding via process connection required Description of cleaning process Information given in operating instructions 						
Exothermic reactions, including self-ignition of dusts	 Provision of material data of the wetted parts for the customer in order to avoid the use of critical media Information given in operating instructions 						

3. Specifications

Pressure limitation

Models 232.50, 233.50, 232.30, 233.30, 262.50, 263.50, 262.30, 263.30, 232.53, 232.54, 233.53, 233.54, PG23LT, PG23CP:

Steady: 3/4 x full scale value Fluctuating: 2/3 x full scale value Short time: Full scale value

Temperature effect

When the temperature of the measuring system deviates from the reference temperature (+20 °C): max. ±0.4 %/10 K of full scale value

Case ingress protection ¹⁾ (per IEC/EN 60529) Model 2xx, PG23CP: IP65, IP66

Model 2xx.3x and back mount: IP54

Model PG23LT for scale range > 0 ... 16 bar: IP66 / IP67

Model PG23LT for scale range ≤ 0 ... 16 bar: IP65

For further specifications see WIKA data sheets PM 02.02, PM 02.04, PM 02.22 and/or PM 02.24 and the order documentation.

1) For general use, no ATEX requirement

4. Design and function

Description

- Nominal size 63 mm
- The instruments measure the pressure by means of resilient Bourdon tube pressure elements
- The measuring characteristics are in accordance with the EN 837-1 standard
- In accordance with the EN 837-1 standard, pressure gauges with "S3" marking are safety pressure gauges whose enclosing and pressurised components are designed with a solid baffle wall. Models with "S3" marking are 232.30, 233.30, 262.30, 263.30. The models PG23LT and PG23CP are optionally available in an "S3" variant.

Scope of delivery

Cross-check scope of delivery with delivery note.

5. Transport, packaging and storage

Transport 5.1

Check the instrument for any damage that may have been caused by transport. Obvious damage must be reported immediately.



CAUTION!

Damage through improper transport

With improper transport, a high level of damage to property can occur.

- ▶ When unloading packed goods upon delivery as well as during internal transport, proceed carefully and observe the symbols on the packaging.
- ▶ With internal transport, observe the instructions in chapter 5.2 "Packaging and storage".



Shocks can cause small bubbles to form in the fill fluid of filled instruments. This has no effect on the function of the instrument.

5.2 Packaging and storage

Do not remove packaging until just before mounting.

Keep the packaging as it will provide optimum protection during transport (e.g. change in installation site, sending for repair).

Permissible storage temperature

■ Models 2xx, PG23CP: -40 ... +70 °C

■ Model PG23LT: -70 ... +70 °C

6. Commissioning, operation



Physical injuries and damage to property and the environment caused by media escaping under high pressure

With the pressurisation of the instrument, as a result of poor sealing of the process connection, media under high pressure can escape.

Due to the high energy of the media that can escape in the event of a failure, the possibility of physical injuries and damage to property exists.

The sealing of the process connection must be carried out expertly and checked for leak tightness.

6.1 Mechanical connection

In accordance with the general technical regulations for pressure gauges (e.g. EN 837-2 "Selection and installation recommendations for pressure gauges").

Instruments must be grounded via the process connection.

This is why electrically conductive sealing should be used at the process connection. Alternatively, take other measures for grounding. Measures for grounding applied ex works (e.g. welding spots or fuse plates) must therefore be used to integrate the devices into the equipotential bonding system and must not be removed under any circumstances. Ensure that the measures for grounding are reinstalled after dismounting (e.g. replacing the device).





For parallel threads, use flat gaskets, lens-type sealing rings or WIKA profile sealings at the sealing face ①. With tapered threads (e.g. NPT threads), sealing is made in the threads ②, using a suitable sealing material (EN 837-2).



The torque depends on the sealing used. In order to orientate the measuring instrument so that it can be read as well as possible, a connection with LH-RH union or union nut should be used. When a blow-out device is fitted to a pressure gauge, it must be protected against being blocked by debris and dirt.

6.2 Requirements for the installation point

If the line to the measuring instrument is not adequately stable, an instrument bracket should be used for fastening (and possibly via a flexible capillary). If vibrations cannot be avoided by means of suitable installation, instruments with liquid filling should be used. The instruments should be protected against coarse dirt and wide fluctuations in ambient temperature.



WARNING!

Physical injuries and damage to property and the environment caused by the back blowing out in the event of a failure

Due to the high energy in the back, if it is blown out in the event of a failure, there is a risk of physical injuries or damage to property through the ejected back and the media that would then escape.

It must be ensured that at no time can personnel or objects be at the rear of the instrument.

6.3 Installation

- Depending on the application, the instrument should be filled with the medium before screwing in, in order to ensure it functions properly.
- Nominal position per EN 837-1 / 9.6.7 figure 9: 90°(\(\pm \))
- Process connection lower mount or back mount
- After installation, open the vent valve (if available) or set from CLOSE to OPEN. The version of the vent valve depends on the model and can deviate from the illustration!



- For outdoor applications, the selected installation location has to be suitable for the specified ingress protection, so that the pressure gauge is not exposed to impermissible weather conditions.
- In order to avoid any additional heating, the instruments must not be exposed to direct solar irradiation while in operation!
- To ensure that the pressure can be safely vented in the case of failure, instruments with blow-out device or blow-out back must keep a minimum distance of 20 mm from each object.

6.4 Permissible ambient and operating temperaturesWhen mounting the pressure gauge it must be ensured that, taking into consideration the influence of convection and heat radiation, no deviation above or below the permissible ambient and media temperatures can occur. The influence of temperature on the indication accuracy must be observed.

6.5 Permissible vibration load at the installation site

The instruments should always be installed in locations free from vibration.

If necessary, it is possible to isolate the instrument from the mounting point, e.g. by installing a flexible connection line between the measuring point and the pressure gauge and mounting the instrument on a suitable bracket.

If this is not possible, the following limit values must not be exceeded:

Frequency range < 150 Hz

Acceleration < 0.5 g (approx. 5 m/s2)

6.6 Level check

For filled instruments, the level must be checked on a regular basis. The liquid level must not drop below 75 % of the instrument diameter.

Commissioning

- Pressure surges must be avoided at all costs, open the shut-off valves slowly.
- The instrument must not be subjected to any external loading (e.g. use as a climbing aid, support for objects).

7. Faults

Personnel: Skilled personnel



CAUTION!

Physical injuries and damage to property and the environment

If faults cannot be eliminated by means of the listed measures, the instrument must be taken out of operation immediately.

- Ensure that there is no longer any pressure present and protect against being put into operation accidentally.
- Contact the manufacturer.
- ▶ If a return is needed, please follow the instructions given in chapter 8.2 "Return".



For contact details see chapter 1 "General information".

Faults	Causes	Measures
No pointer movement despite	Movement blocked.	Replace instrument.
change in pressure.	Pressure element defective.	
	Pressure port blocked.	
After depressurisation, the	Friction in the movement.	Tap lightly on the case.
pointer remains just above the zero point.	Instrument was overloaded.	Replace instrument.
zero point.	Material fatigue of the pressure element.	
The pointer remains outside the zero point tolerance	Mounting error: Instrument not mounted in nominal position.	Check the mounting position.
after installation and depressurisation.	Transport damage (e.g. non-permissible shock loading).	Replace instrument.
Instrument outside the accuracy class.	Instrument was operated outside of permissible performance limits.	Check the observance of the operating parameters of the application. Replace instrument.
Vibration of the pointer.	Vibrations in the application.	Use instrument with case filling.
Mechanical damage (e.g. window, case).	Improper handling.	Replace instrument.

For the replacement of the instrument chapters 9 "Dismounting, return and disposal" and 6 "Commissioning, operation" must be observed.

8. Maintenance and cleaning

8.1 Maintenance The instruments are maintenance-free.

The indicator and switching function should be checked once or twice every year. For this the instrument must be disconnected from the process to check with a pressure testing device. Repairs must only be carried out by the manufacturer or appropriately qualified skilled personnel.

8.2 Cleaning



CAUTION! Clean the pressure gauge with a moist cloth.

- Wash or clean the dismounted pressure gauge before returning it, in order to protect
- personnel and the environment from exposure to residual media.

9. Dismounting, return and disposal



WARNING Residual media in dismounted pressure gauges can result in a risk to persons, the

environment and equipment. Take sufficient precautionary measures.

Dismounting

Only disconnect the pressure gauge once the system has been depressurised! When dismounting, close the vent valve (if available).

9.2 Return

Strictly observe the following when shipping the instrument: All instruments delivered to WIKA must be free from any kind of hazardous substances (acids,

bases, solutions, etc.) and must therefore be cleaned before being returned.

When returning the instrument, use the original packaging or a suitable transport packaging.

9.3 Disposal

Incorrect disposal can put the environment at risk. Dispose of instrument components and packaging materials in an environmentally compatible way and in accordance with the country-specific waste disposal regulations.



EU-Konformitätserklärung EU Declaration of Conformity

11564220.04

Wir erklären in alleiniger Verantwortung, dass die mit CE gekennzeichneten Produkte We declare under our sole responsibility that the CE marked products

Typenbezeichnung: Type Designation:

sounly mat the C-E marked product 233.50.063 + option ATEX / 232.50.063 + option ATEX / 233.50.100 + option ATEX / 233.50.100 + option ATEX / 233.50.100 + option ATEX / 235.50.100 + option ATEX / 263.50.063 + option ATEX / 263.50.063 + option ATEX / 263.50.063 + option ATEX / 263.50.100 + option ATEX / 263.50.100 + option ATEX / 263.50.100 + option ATEX / 263.50.160 + o 282.50.160 + option ATEX / 283.50.160 + option ATEX / 223.30.063 + option ATEX / 223.30.063 + option ATEX / 223.30.100 + option ATEX / 223.30.100 + option ATEX / 223.30.100 + option ATEX / 223.30.160 + option ATEX / 283.30.163 + option ATEX / 283.30.063 + option ATEX / 283.30.100 + option ATEX / 282.30.100 + option ATEX / 283.30.100 + option A 232.53.063 + option ATEX / 233.53.063 + option ATEX / 232.54.063 + option ATEX / 232.54.063 + option ATEX / 232.55.109 - option ATEX / 232.55.109 - option ATEX / 232.55.109 + option ATEX / 232.55.109 + option ATEX / 233.54.100 + option A

232.36.100 + option ATEX / 233.36.100 + option ATEX / 232.36.160 + option ATEX / 233.36.160 + option ATEX /

PG23LT.063 + option ATEX / PG23LT.100 + option ATEX / PG23LT.160 + option ATEX / PG23CP.063 + option ATEX / PG23CP.100 + option ATEX

Druckmessgerät mit Rohrfeder Bourdon Tube Pressure Gauge

gemäß gültigem Datenblatt: according to the valid data sheet: PM 02.02, PM 02.04, PM 02.12, PM 02.15, PM 02.22, PM 02.24

die wesentlichen Schutzanforderungen der folgenden Richtlinien erfüllen: Harmonisierte Normen: comply with the essential protection requirements of the directives: Harmonized standards:

2014/34/EU Explosionsschutz (ATEX) (1) Explosion protection (ATEX) (1)

Ex II 2G Ex h IIC T6...T1 Gb X
II 2D Ex h IIC T85 °C...T450 °C Db X

EN ISO 80079-36:2016 EN ISO 80079-37:2016

(1) Moduli A, Interner Fertigungskontrolle. Die Dokumentation ist hinterlegt bei notifizierter Stelle TÜV NORD CERT GmbH, Esser (Nr. 0344), Asternummer 8000580028.
Module A, Internel control of production. The Documentation is deposited at notified body TÜV NORD CERT GmbH, Esser (no. 0044), reference number 8000580028.

WIKA Alexander Wiegand SE & Co. KG

Klingenberg, 2019-05-03

Alfred Hafner, Vice President
Process Instrumentation Pressure

14 Michael Glombitza, Head of Quality Manager Process Instrumentation Pressure

Kommanditgessilschaft Sitz Küngenberg – Amtuvericht Auchaffenbare (190, 1919)

de

WKA Alexander Wiegand SE & Co. KG Alexander-Wiegand-Straße 30 63911 Küngenbarg